

Please read the manual before using the product. The manual and carton contain important information, please keep them properly for later references. If failure to following the instruction in the manual, it might be dangerous for your child.

In order to improve the product and quality, we may change the parts of structure, appearance, packing method, assembly method and function of the product without any notice. When there is any difference between the manual and the product, please refer to the actual product. We are sorry for any inconvenience.



If you are experiencing any difficulties with this product, please contact Plan B International: +613 9432 7111 for service assistance.

The assembly manual of battery operated car
Model: SX1918



WARNING











Products should be assembled by an adult. Protective equipment should be worn. Not to be used in traffic. Not suitable for children under 3 years. Choking hazard - Small parts. In unassembled state, contains potentially hazardous small parts. Please keep out of the reach of small children. Pay attention to the potential hazards of using the toy in areas other than private grounds.



WARNING

Allowed one rider at a time. Adult supervision required. Do not use on public roads, hills, sloped, driveway, near motor vehicles or swimming pools.

PARTS LIST

PARTS NAME	PICTURE	QTY	PARTS NAME	PICTURE	QTY
Car body		1PC	Saddle		1PC
Mirror		2PC	Steering wheel		1PC
Spoiler		1PC	Windshield		1PC
Wheel		4PC	Charger		1PC
Hardware package		1PC			
User manual		1PC			



PRODUCT SPECIFICATIONS

Battery	6V-4.5AH*2
Main material	PP
Suitable age	3-8 Years
Weight limit	30kg
Product size	116 x 58 x 46cm
Speed	3-5KM/Hour
Runtime	1-2 hours after charging for 8-12 hours, based on ride on conditions
Charger	Input: 220-240V, Output: 15V 0.8A
Fuse	Auto-reset fuse

This toy contains batteries that are non-replaceable

STROLLER FUNCTION

Pull out the handle and caster wheels out if needed. When not needed, push them back to save space.




ASSEMBLY INSTRUCTION

- Car assembling should be done by adults.
- Take care of small parts. To avoid choking hazard, keep children away while assembling. Children under 36 months are prohibited to use.
- Please count all the parts carefully before assembling and dispose the plastic bag properly.

1. Front wheel assembly


Turn over the car body, aim the front wheel center to front axle, press the button on the middle of the wheel, then insert and push the wheel into place.



2. Rear wheel assembly


Driving wheel is different with the non-driving wheel. Driving wheel should be attached with the motor. There is a bulge plastic part inside the driving wheel. Installation method is same.

Aim the rear wheel center to rear axle, press the button on the middle of the wheel, then insert and push the wheel into place.




3. Windshield assembly

Aim the hooks under front windshield to the appropriate position, push down and fix with screws.




4. Steering wheel assembly

Connect steering wheel wire to the wires coming out of the steering column and match connectors. Insert the steering wheel into the steering column and fix with spring clip. Mechanical steering wheel can't be adjusted.




5. Saddle assembly

Align two plastic hooks with corresponding openings on the car body, push them into place, fix the back of the saddle with a screw.




6. Mirrors assembly

Align mirrors with corresponding openings on the car body, push them into place.




7. Spoiler assembly

Align spoiler with corresponding openings on the car body, push it into place.



8. Battery connection

Loosen the two screws on the bonnet, remove the bonnet, connect two red clip locks of two wires. The two screws on the hood have a gasket. When the screws are loosened, they can't be completely unscrewed or the gasket will fall off.



WARNING:

This product is not a vehicle for transportation, it should be used under adult guidance. Parents should ensure that children have taken the safety measures before using.

When changing the gears, the accelerator should be released and the car has completely come to a stop. Prohibit to change the gear while the car is still moving, because that can damage the wire and other transmission parts.


FUSE

This car has the auto-reset fuse, if the car stops suddenly during driving, it is mainly caused by instantaneous current exceeds, which causes the fuse to trip. Then just stop operating for about 8 seconds, and this fuse can be reset.

Then turn on the power switch again.

In order to avoid the fuse tripping and cutting off power supply, please pay attention to the following matters:

This product can't be overloaded, the maximum load is 30kgs.



Don't drag anything behind products.

Don't let the water or other liquid into the batteries and other electrical components.

Do not change the circuit system and the structure of the product.

SECURITY WARNING

- 1.The installation and charging of vehicle should be under adult supervision at all times.
- 2.This product is limited to the children from 3-8 years old and 30 kg maximum weight limit, please do not overload.
- 3.This product is ideal for driving on a hard flat surface.
- 4.It is strictly prohibited in the streets or the road, pot holes, and slopes.
- 5.Avoid driving in the sand or grass or uneven ground.
- 6.Children should be given full instructions on operation of the car. Improper operation can cause damage or accidents.
- 7.While children are driving, it is parents' duty to supervise at all times to avoid accidents.
- 8.Avoid driving in rains or flooded pathways. By doing so it can damage the motor, circuit and other electrical equipments.
- 9.Battery charger should be regularly inspected by parents to insure that the wires, plugs, crusts and other components are not damaged. Please stop using if any damage is found, until it is completely restored.
- 10.In order to ensure product life and safety, avoid damage to the charger, battery or electric circuit, the car must use the default configuration of a dedicated charger and power supply.
- 11.Rechargeable batteries should be removed from the toy before charging.
- 12.When product is not in use, please cut off the product power, and keep all the switches to "stop" or "off" position.
- 13.The charger provided is not a toy. It is to be kept away from children.
- 14.Strictly prohibit using the non-manufacturer provided parts.
- 15.This product is made of PP material mainly, and the safe using time is two years.

USAGE DIRECTION

1. Before using it, make sure that all the following works are done.

- Step described in accordance with the instructions to complete the installation of the car, the battery plug-in has been connected, the power supply has been switched on.
- Make sure that all the positions which need the screws are fixed tightly.
- Parents or guardian should ensure that children have taken the safety measures before using.

To reduce risk when using this product, please pay attention to the following:


- When driving the car, child should sit on the car seat.
- Adult or parents should supervise child at all times.
- Pay attention to the driving environment and ensure that driving surface is the appropriate hard, flat surface and not any unsafe environments.

Examples of unsafe environments:


- a. The trenches, the riverside, slope or uneven ground;
- b. Road or other places for driving and walking;
- c. Any obstructions which can be easily hit and cause injury;
- d. Other unsafe zones.

To avoid an accident, please use only during the day and in bright environments. Avoid using in low visibility.

2. Operating(function reference diagram)



MP3



CHARGING WAY

For Safety purposes, the charging must be done by adults. When it is the first time to use, open the engine bonnet, remove the engine plastic cover, connect two red clip locks of two wires. Please charge 8 to 12 hours.

If the car has slowed down, it needs to be charged for 8 to 12 hours, maximum 20 hours.

1.First insert the plug of the charger into the charging port.

(The car power will be cut off)

2.Then insert the charger to the power socket.

