

Assembly Instructions

42985099 2 SECTION WARDROBE











ATTENTION:

DO NOT TIGHTEN THE SCREWS UNTIL THE PRODUCT IS FULLY ASSEMBLED.












FOR INDOOR USE ONLY

MAXIMUM LOADING WEIGHT: 10KG FOR CLOTHES RAIL, 6KG FOR TOP SHELF, 5KG FOR EACH MIDDLE SHELF, 12KG FOR BOTTOM SHELF.


1 Hardware list

	a	M6X28mm	14pcs		f	6pcs
	b	M5X40mm	12pcs		g	2pcs
	c	M6X16mm	2pcs		h	2pcs
	d	M6X12mm	2pcs		i	2pcs
	e	M4X12mm	4pcs		j	3pcs

2

		
A 1PC	B 1PC	C 1PC
		
D 1PC	E 1PC	F 1PC
		
G 1PC	H 1PC	I 1PC
		
J 3PCS	K 1PC	

3




TOPPLING FURNITURE WARNING:

- >IT IS STRONGLY RECOMMENDED THAT THIS PRODUCT IS PERMANENTLY FIXED TO THE WALL.
- >PLEASE SEEK PROFESSIONAL ADVICE IF YOU ARE IN DOUBT OF WHAT FIXING DEVICE TO USE.
- >REGULARLY CHECK THAT ANCHORS ARE SECURELY MAINTAINED.
- >STABILITY OF TALL ITEMS MAY BE AFFECTED BY THICK PILE CARPET OR UNEVEN FLOORS.
- >DO NOT PLACE UNANCHORED TELEVISIONS ON FURNITURE.

CAUTION: FOR YOUR SAFETY WHEN ATTACHING THE ANCHOR FIXINGS, PLEASE NOTE THE FOLLOWING:

- >CHECK ANY ELECTRICAL WIRES OR PLUMBING INSIDE THE WALL BEFORE DRILLING ANY HOLES (IF YOU ARE UNSURE PLEASE SEEK PROFESSIONAL ADVICE FROM A QUALIFIED TRADESPERSON).

STEP 1




 f x 2

 d x 2


 c x 2


STEP 2




 f x 4


STEP 3




 b x 12

STEP 4




 a x 8

STEP 6



 e x 4

STEP 5



 a x 6

STEP 7

