


INSTRUCTIONS

KEYCODE: 42990512

DESCRIPTION: FARM PLAYSET



Age grading: 3+ years


Adult assembly required.

WARNING:


- The toy is to be assembled by adult.
- Read all the instructions before assembly and use of the product .
- Philips screwdriver (not included) is required for assembly.
- Take care when unpacking and during assembly.
- Dispose of all packing materials carefully after assembly.
- Regularly check that all fittings remain tight. Tighten if required.
- Inspect the product before assembly and periodically during use. Never use this product if there is any loose or missing fasteners, joints or broken parts.
- Never substitute parts.

CHOKING HAZARD: Contains assembly components that are small parts with functional sharp points and edges. Keep away from children under the age of 3 years.


①




②



③



④



⑤

