KMT说明书 折页 128g双铜 尺寸: 89*127mm

anko

12 month warranty

Thank you for your purchase from Kmart

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with the accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.Please retain your receipt as proof of purchase and contact our Customer Service Centre on 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or alternatively, via Customer Help at kmart.com.au for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

- This Bluetooth earbuds shall be charged by the supplied charging unit only.
 Battery cannot be subjected to high or low extreme temperatures, low air pressure at high altitude during use, storage or transportation.
 Replacement of a battery with an incorrect type that can result in an explosion or the leakage of
- Replacement of a pattery with an information type and fammable liquid or gas.

 Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
- can result in an explosion.

 Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.

 A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

Bluetooth® Headphones


Operating instructions

- Includes:
 Bluetooth headphones
- Charging cable





Function overview:



Power ON

Power OFF

Long press power button,

Long press power button ,

Red and blue LED flashes quickly

How to use these headphones:

Function Operation Pause Short press >II button 1 Play Short press > | button (1) Next Song Short press >>/+ button 2 Previous Song Short press >>/- button 2 Volume Up Long press >>/+ button when the volume is adjusted to maximum you will LED indicates Red then turn off

hear a voice indication tone Volume Down Long press >>/- button

Pairing the headset with Bluetooth devices

- Once the headphone is powered on, it is in pairing mode (LED flashes) slowly) and will pair to the last paired device(if available).
- Pair the headset in Bluetooth menu in mobile phone and once it is paired, you can hear a pairing tone and the LED will flash very slowly. Bluetooth Name: anko 43030682

- Press power button to pick up/hang up phone calls.
- Double click the power button to call the previous number dialed.

Playing music

When the headset connects with the mobile phone via Bluetooth you can enjoy music through the headset wirelessly.

headphone cable and listen to music when the cable is connected directly to your music device via its headphone

This function can still be used when the headphones battery is flat.

Battery Charging This Bluetooth heaset battery is

rechargeable.

Please use the accessory USB cable to

- recharge the battery.

 Insert USB charging cable into a
- suitable USB port.

 Connect charging cable with the
- headset USB port.
- Indicator LED turns RED to show
- battery is charging. • Indicator LED turns OFF when battery
- is fully charged
- It takes about 2 hours to fully charge the battery.

Specifications: Model No:

43030682 Support profiles: A2DP, AVRCP, HFP Working Distance: 10 meters Music Time : Talk time: >10 Hours Standby time: >60-100 Hours

Charging voltage: 5V d.c Charge time: Aux Cable length: 1 m Pairing window time: 4 minutes Non-play automatic power save mode

after 30 seconds the headphone will enter power save mode and then automatically switch off when the low battery alarm sounds.

The Bluetooth@ word mark and logos are registered trademarks owned by Bluetooth@ SIG, Inc., and any use of such marks by KMART AUSTRALIA is under licence