



WARNING!

THIS MUST BE ASSEMBLED BY AN ADULT BEFORE USE.
THIS PRODUCT CONTAINS SMALL PARTS AND IS NOT SUITABLE FOR CHILDREN UNDER 36 MONTHS. SMALL PARTS. CHOKING HAZARD.
CHILDREN MUST NOT USE THE EQUIPMENT UNTIL PROPERLY INSTALLED.
ONLY FOR DOMESTIC USE.
FOR OUTDOOR USE.
ADULT SUPERVISION IS REQUIRED.
RETAIN PACKAGING FOR FUTURE REFERENCE.
THIS PRODUCT IS INTENDED FOR USE BY CHILDREN AGED 6+ YEARS.
CHECK ALL FASTENINGS REGULARLY AND OFTEN. FAILURE TO DO THIS MAY RESULT IN THE PRODUCT MALFUNCTIONING, AND CAUSING INJURY.





Trampoline Ladder

Key code: 43032853

INSTRUCTIONS FOR ASSEMBLY AND USE.

PLEASE RETAIN FOR FUTURE REFERENCE.

1	Top tube x2	U shape tube x1	M6 Nut x6	M6 x 30mm Screw x2	Allen key x1		<input checked="" type="checkbox"/>
	Middle tube x2		M6 Spacer x4	M6 x 42mm Screw x4			
	Step x2						
	Plastic spacer x2				Spanner x1		<input type="checkbox"/>

