

# Light up Play Tent Pink

Key Code: 43073863

## Parts list:

- Tent pole x 4pc (when fully assembled)
- Tent x 1pc
- Light x 1pc
- Carry bag x 1pc

## Assembly Instructions:

Step 1: Connect each of the short poles together to form four long poles.



Step 2: Unfold the tent to form a round shape.



Step 3: Insert one end of the poles into the pink pockets located at the tip of the tent and insert the other end of the poles into the black pockets located at the bottom of tent. Tie the straps together with the poles, then the tent assembly is finished.



## Folding Instructions for tent:

Remove all the poles first, and fold the tent to form a round shape, then fold it from diameter direction and keep the outer side point in the hand lower than the inner side one. Pull the front point with your left hand down side towards the right hand, so the spring frame will be folded completely. Then wrap it with elastic string.



## **WARNING!**

1. Read instructions carefully before assembly.
2. Adult assembly required.
3. Pull out the insert between the battery on the light when using the product for the first time.
4. Keep away from fire. Never allow a naked flame near this product, the fabric will burn if left in continuous contact with flame and heat sources.
5. This product has an internal spring frame that will pop open with some force when opened. Never let small children unfold or fold this product. Caution must be used in the handling of this product.
6. For indoor use only.
7. This product contains Non-Replaceable Button Cell Batteries.
8. Please keep this instruction for future reference.

### **Care Instruction:**

- .Wipe clean with damp cloth, do not use abrasive material or solvents.
- . Ensure the tent is clean and dry thoroughly before storage.
- . Always turn off the light and store in a dry place when not in use.



**WARNING: Button cell Batteries are Hazardous (new or used). Keep away from Children. Button Cell Batteries can cause severe or fatal injuries in 2 hours or less if they are swallowed or placed inside any part of the body. If you suspect your child has swallowed or inserted a button cell battery, call the 24hour poisons information centre in Australia on 131126 or in New Zealand 0800 764 766 or contact your country's emergency dept. Used batteries must be disposed of in the garbage or a battery recycle facility.**

**FOR AU/NZ: IMPORTED FOR KMART STORES IN AUSTRALIA AND NEW ZEALAND.**

Made in China