



On-Ear Bluetooth[®] RGB Headphones

Operating instructions

Includes:

- › Bluetooth[®] headphones
- › charging cable
- › audio cable




K: 43-105-250 | T: 68-736-194
MODEL: 43105250

Bluetooth name is KM43105250

This product shall be supplied by a power source not exceeding PS1 only. › This Bluetooth headphone shall be charged by the supplied charging unit only.
CAUTION › The batteries in this product are not replaceable. › Use, storage or transporting the battery should not be subjected to extremely low temperatures, or low air pressure at high altitude. › If the battery is exposed to extremely high temperatures it could result in an explosion or the leaking of flammable liquid or gas. › Please take care when disposing of the unit; disposal in a fire, oven, mechanically crushing or cutting machine could cause explosion.

How to use these headphones:



Function Operation:

Play: Press ● button

Pause: Press ● button

Previous Track: Press – button

Next Track: Press + button

Answer Call: Press ● button

End Call: Press ● button

Reject Call: Press and hold ● button for approx. 2 seconds

Redial Last Call: Press + button twice

Volume Up: Press and hold + button

Volume Down: Press and hold – button

Activate Phone Assistant: Press and hold ● button for approx. 2 seconds

Power ON: Press and hold the power ● button until blue and red indicator light flashes

Power OFF: Press and hold the power ● button until red indicator light start flashing

LED ON: Press the power ● button twice to turn LED on

LED OFF: Press the power ● button twice again to turn LED off

Pairing the headset with Bluetooth devices

- › Once the headphone is powered on, you will hear a voice prompt “power on”, the headphone will then pair to the last paired device.
- › If not previously paired, search on your electronic device’s Bluetooth menu and select the pairing name **KM43105250**.
- › Once connected you will hear a voice prompt “the Bluetooth device is connected sucessfully”.
- › To disconnect current connected device, the headphone will go to pairing mode again with red and blue LED flashing and is available to be connected with a different device.

TF Card

- › Insert TF card (up to 32GB, TF card not included) into the TF card slot, the music on TF card will automatically be played by the headphone.
- › When a TF card is inserted, the Bluetooth function of headphone will temporarily turn off, the headphone will no longer be connected to the mobile phone, and cannot be used to make or answer calls through the headphones. Press ● button 3 times to switch to Bluetooth mode.

Aux Mode

- › To switch to Aux mode, insert the Aux Cable into the headphone and the 3.5mm Jack end into your mobile device or computer. Bluetooth mode will automatically switch off.

Battery Charging

- › Please use the provided USB cable to charge the battery.
- › Insert the micro USB cable end into the headphone charging port.
- › Insert USB charging cable into an appropriate 5V 1A USB port.
- › The LED will turn red when charging and turn blue when the headphone is fully charged.
- › It takes max 3 hours to fully charge the battery.

Specifications:

Version: V5.0

Support profiles:

A2DP1.3/HFP1.6/HSP1.2/AVRCP1.6

Working distance: 10 metres

Music time: Approx. 18 hours

Talk time: Approx. 18 hours

Standby time (powered): Approx. 40 hours

Charging voltage: 5V d.c.

Charge time: Approx. 3 hours

Pairing window time: 5 minutes

12 Month Warranty

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations for instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expenses incurred in returning this product can be addressed to the respective Customer Services Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

MADE IN CHINA

CUSTOMER SERVICE:

KMART AU: 1800 124 125

KMART NZ: 0800 945 995

TARGET AU: 1300 753 567

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc., and any use of such marks by KMART AUSTRALIA is under licence.



WARNING Do not dispose of unit in fire or water. › Never attempt to disassemble and reassemble. › Waste electrical products should not be disposed of with household waste, please recycle where facilities exist. › Check with your local authority for recycle advice. › Keep your device and all accessories out of the reach of children and animals. › Small parts may cause choking or serious injury if swallowed. › Avoid exposing your device to very cold or very hot temperatures (below 0°C or above 45°C). › Extreme temperatures can cause deforming of the device and reduce the charging capacity and life of your device. › Do not allow your device to get wet—liquids can cause serious damage. › Do not handle your device with wet hands.