

anko

User Manual LED Monitor Light with Webcam Keycode:43126477

Notice :

Please read user manual carefully before any operations and keep it for your records.




Safety instructions:

1. This product is for indoor use only.
2. This product might be turned on or off under strong electromagnetic wave.
3. The light source in this lamp shall be replaced by the manufacturer or its service agent or someone with similar qualifications.
4. When the moving part of the product is stretched to the limited position, don't pull strongly to avoid damage.
5. Suggest to adjust the light mode to normal or warm at night.
6. To take care of the children, to ensure that they won't play the wireless charger as a toy.

Packaging content:

1. Monitor Clip Light and Web Cam x 1
2. USB to Type-C Charging cable x 1
3. Instruction manual *1

Product instructions:



1. Light ON/OFF button
2. Light mode switch button
3. HD 1080p lens
4. Microphone
5. Flexible clip/base
6. Activity light
7. Type-C port

Place the light

Grasp the light as shown and open the flexible clip/base with the other hand. Mount the light, making sure the foot on the flexible clip/base is flush with the back of your monitor

Connect the webcam

Connect the device to a computer USB port, The Windows® UVC or Mac drivers will loaded automatically. Driver installation may take a few moments. The webcam does not ship with video calling software. To make a video call, use your video calling application

Use the monitor clip light

1. Connect the USB cable to the power input port, and the other end of the cable to any device with a 5V/1A USB output.
3. Touch the ON/OFF button to turn on/off the light, long press to adjust the brightness.
4. Touch the light mode switch button to switch light mode: warm – cool –normal, long press to adjust the temperature.

Specification:

Input: DC5V/1A

LED: 60 pcs

Material: Aluminum + ABS

Resolution: HD 1080P

Color temperature: 2800K/4500K/5500K

12 Month Warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or alternatively, via Customer Help at Kmart.com.au for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.