



314 Litre Top Mount Refrigerator Freezer **Quick Start Guide**



Model no: ATM314X

Rev: 02

A simple guide to start using your 314L Top Mount Refrigerator Freezer

› Installation Tips

Two person installation: Use two or more people to move and install the appliance. Failure to do so can result in back or other injury.

Freestanding design: This appliance is designed to be freestanding only, and should not be recessed or built-in.


Floor surface: This appliance must be properly positioned on a dry, sturdy, level surface that is strong enough to support it when it is fully loaded.

Ambient temperature: The ambient temperatures must correspond to the climate class (T) indicated on the rating plate of the appliance: 16°C – 38°C.

Clearances: Ensure that air can circulate freely around the back of the cabinet, which is necessary to cool the compressor and condenser. Allow at least 10cm clear space at the back, 10cm at the sides of the unit and 30cm between the top and any surface above. If you are installing your refrigerator next to a fixed wall, leave sufficient space on the hinge side to allow for the door to swing open.

Note: For further installation instructions please refer to the user manual.

› Temperature Control



The temperature controls are located on the inside of the fridge. Use the SETTING button (A) to cycle through the temperature settings from COLD (1) to SUPER COOL (4).

- › 1: The warmest temperature setting
- › 2-3: Normal operation (adequate for most situations)
- › 4: Super Cool is used to get to a colder temperature in a quicker time frame

› First Use

When starting up for the first time, keep the refrigerator still for 2 hours before connecting it to power supply.

Before putting any fresh or frozen foods in the fridge, ensure the fridge has run for 2-3 hours, or for at least 4 hours in summer when the ambient temperature is high.

› Product Specifications

Capacity	314L
Dimensions (w,d,h)	595 x 695 x 1620mm
Net Weight	55kg
MEPS	3 Stars

› Need Help?

For all questions or customer support please contact us using the details below.

Phone 1800 124 125 (Australia)
Online www.kmart.com.au