anko

Car Charger USB-C 30W

Operating instructions



K: 43-277-377 | T: 68-736-286 MODEL: 43277377

Product Overview

- 1 USB-C Output port
- 2 Indicator light



Specification:

- > input: DC12-24V, 2.7A
- output: 5.0V=3.0A 9.0V=2.77A 12.0V=2.5A
- 15.0V=2.0A 20.0V=1.5A (Max 30W Fast Charging)
 15V & 20V Output are only supported when 24V input
- > dimensions: 65 x 30 x 27 (mm)

Operation:

- 1. Connect power: Plug the car charger into car socket.
- 2. Charging: Connect one end of charging cable to your device's charging port.
- 3. The blue indicator light remains lit when connected.
- 4.15V & 20V Outputs only available with 24V input.

Caution:

- > To prevent fire or electric shock, Keep away from liquids and moisture.
- Do not operate this car charger with a damaged plug.
- This adaptor is not intended for use by children.
 Adult supervision is required at all times when children are present.

In case of emergency, discontinue use immediately. Unplug the car charger from the electrical socket only when safe to do so.

For example:

- > Smoke from the unit
- Changed shape
- › Liquid leakage

12 Month Warranty

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations for instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand lexislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expenses incurred in returning this product can be addressed to the respective Customer Services Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

MADE IN CHINA

CUSTOMER SERVICE: KMART AU: 1800 124 125 KMART NZ: 0800 945 995 TARGET AU: 1300 753 567



WARNING do not dispose of unit in fire or water. > Never attempt to disassemble and reassemble. > Waste electrical products should not be disposed of with household waste, please recycle where facilities exist. > Check with your local authority for recycle advice. > Keep your device and all accessories out of reach of children and animals. > Small parts may cause choking or serious injury if swallowed. > Avoid exposing your device to very cold or very hot temperatures (below 0°C or above 45°C). > Extreme temperatures can cause deforming of the device and reuce the charging capacity and life of your device. > Do not allow your device to get wet-liquids can cause serious damage. > Do not handle your device with wet hands.