

Assembly Instructions

43283415 OPEN DOLLHOUSE

WARNING: DO NOT STAND ON THE UNIT. ENSURE THIS UNIT IS USED ONLY ON A FLAT SURFACE. DO NOT USE THIS UNIT UNLESS ALL BOLTS AND SCREWS ARE FIRMLY SECURED. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.

CARE INSTRUCTION: WIPE CLEAN WITH A SOFT DAMP CLOTH. NEVER USE SCOURERS, ABRASIVES OR CHEMICAL SOLVENTS. KEEP AWAY FROM MOISTURE AND DIRECT SUNLIGHT. STORE IN A DRY PLACE. CHECK AND TIGHTEN ALL PARTS REGULARLY. FOR INDOOR USE ONLY.
















MAXIMUM SAFE LOAD: 3KG FOR EACH SHELF.




















WARNING! NOT SUITABLE FOR CHILDREN UNDER 3 YEARS. CONTAINS SMALL PARTS.


WARNING: THIS IS A TOY, INTENDED FOR ROLE PLAY ONLY. ADULT ASSEMBLY IS REQUIRED. UNASSEMBLED PARTS CONTAIN SCREWS AND WITH FUNCTIONAL SHARP POINTS, PLEASE KEEP UNASSEMBLED PARTS AWAY FROM SMALL CHILDREN. ADJUSTING SHELVES MUST BE DONE BY AN ADULT. PLEASE CHECK CONDITION OF PRODUCT REGULARLY, AS HARDWARES MAY LOOSEN WITH USE OVER TIME. TIGHTEN THE HARDWARE FITTINGS IF NECESSARY.

WARNING: PLEASE SECURE THIS PRODUCT WITH THE SUPPLIED WALL FIXING. IT IS STRONGLY RECOMMENDED THAT THIS PRODUCT IS PERMANENTLY FIXED TO THE WALL. PLEASE SEEK PROFESSIONAL ADVICE IF YOU ARE IN DOUBT OF WHAT FIXING DEVICE TO USE. REGULARLY CHECK THE ANCHOR IS SECURELY MAINTAINED.

Hardware list


	a	M3x25mm	26pcs		h		8pcs
	b	M5x25mm	24pcs		i		2pcs
	c	M4x55mm	8pcs		j	M3.5x10mm	8pcs
	d	M6x55mm	8pcs		k		4pcs
	e		8pcs		l	M6x30mm	8pcs
	f		8pcs		m	M4x20mm	16pcs
	g	M4x45mm	1pc		n	M4x30mm	2pcs
					o		18pcs

	①	1pc		②	1pc		③	1pc		④	1pc		⑤	1pc
	⑥	1pc		⑦	1pc		⑧	1pc		⑨	1pc		⑩	1pc
	⑪	2pcs		⑫	2pcs		⑬	4pcs		⑭	4pcs		⑮	2pcs
	⑯	1pc		⑰	1pc		⑱	1pc		⑲	2pcs			




STEP 1

- a x 6
- b x 6




STEP 2

- a x 4
- b x 4




STEP 3

- a x 4
- b x 4






STEP 4

- i x 2
- j x 8
- n x 2




STEP 5

-  a x 4
-  b x 4







STEP 6

-  a x 2






STEP 7

-  a x 6
-  b x 6
-  k x 4




STEP 8

-  l x 8
-  c x 8






STEP 9


 m x 16



x4




STEP 10

 d x 8
 e x 8
 f x 8



Make sure the legs fit the bottom board tightly before fully tightening the screws.

STEP 11


 g x 1  o x 18
 h x 8

User instructions should include the wording:

- It is strongly recommended that this product is permanently fixed to the wall with the supplied wall fixings.
- Please seek professional advice if you are in doubt of what fixing device to use.
- Regularly check that anchors are securely maintained.
- Stability of tall items may be affected by thick pile carpet or uneven floors.

CAUTION: for your safety when attaching the anchor fixings, please note the following:

- Check for electrical wires or plumbing inside the wall before drilling any holes. If you are unsure, please seek professional advice from a qualified tradesperson.



When assembling 15, the holes of the plate should be aligned with h

STEP 12



WARNING! NOT SUITABLE FOR CHILDREN UNDER 3 YEARS. CONTAINS SMALL PARTS.



WARNING: PLEASE SECURE YOUR PRODUCT WITH THE SUPPLIED WALL FIXINGS. SCAN THE CODE FOR MORE INFORMATION.

