



Wooden Mud Kitchen

614U



Instructions for assembly, maintenance and safe use.





WARNINGS!

- THIS PRODUCT CONTAINS SMALL PARTS AND IS NOT SUITABLE FOR CHILDREN UNDER 36 MONTHS.
 SMALL PARTS ARE A CHOKING HAZARD.
- THIS PRODUCT IS INTENDED FOR USE BY CHILDREN AGED 3+ YEARS.
- ONLY FOR DOMESTIC USE. FOR OUTDOOR USE ONLY.
- TOY MUST BE ASSEMBLED BY AN ADULT BEFORE USE.
- CHILDREN MUST NOT USE THIS PRODUCT UNTIL PROPERLY INSTALLED.
- ADULT SUPERVISION REQUIRED.


- REMOVE ALL PACKAGING BEFORE GIVING TO YOUR CHILDREN.
- RETAIN PACKAGING FOR FUTURE REFERENCE.
- · PLEASE RETAIN INSTRUCTIONS AS IT CONTAINS IMPORTANT SAFETY INFORMATION.
- POTS AND PANS FOR USE IN ROLE PLAY ONLY.
- WATER MAY BECOME CONTAMINATED EMPTY WATER AFTER EACH USE.
- DO NOT SIT ON, OR OVERLOAD THE WORKTOP.


INSTRUCTIONS FOR ASSEMBLY, MAINTENANCE AND SAFE USE.


PLEASE RETAIN THIS INFORMATION FOR FUTURE REFERENCE.


- 1. Toy must be assembled by an adult before use exactly in accordance with the instructions.
- 2. Children must not use this product until properly installed.
- Check all parts are present before you start to assemble the product. Place small parts on a tray or similar to ensure they are not lost. The manufacturing process can very occasionally result in sharp edges/waste material so please take care when assembling this product.
- 4. If any parts are missing do not use the product until the replacement parts are fitted.
- Ensure your product is sited on level ground. Failure to do this may put additional stress on connections and joints and in time could cause them to fail.
- Ensure your product is located on a soft impact surface like grass. Never locate your product on hard surfaces like concrete.
- 7. Avoid locating this product in full sun.
- 8. Remove all packaging before giving to your children.
- Equipment should be checked by an adult at the beginning of each season and at regular intervals during the usage season to ensure it is safe. Pay special attention to all connections and fastenings.
- Parts may need to be replaced if they show signs of wear and tear. Replace any defective parts in accordance with these instructions.
- 11. Due to the natural characteristics of timber, it is vital to check your playframe regularly for splintering, lifting of surface layers of wood or exposure of rough wood. Affected areas must be rubbed down using coarse sandpaper to restore a smooth, safe surface.


- Any changes to this toy eg changing or adding an accessory, must be done in accordance with our instructions. Failure to do this will render your guarantee null and void and may make your product unsafe.
- 13. Ensure children's clothing is appropriate for the play activity.
- 14. Never place toys near a fire.
- 15. In high winds, ensure outdoor toys are moved to a sheltered position and/or securely
- 16. The age recommendation for this product is clearly stated on the packaging and in these instructions. Please adhere to it at all times. Adult supervision is required at all times to ensure children play safely.
- 17. When you dispose of this equipment please do so responsibly.












Safe Play Area




EN


The safe play area refers to the zone extending 200cm around the toys on all sides and 250 cm above the toy. The safe play area must be free from all obstacles.

Wood Treatment

Wood treatment not supplied




Contents



SCREWS











FA4526 3.5 x 30mm wood screw **x41**

FA4523 3.5 x 50mm wood screw **x11**















B 1 13 A () FA4526 3.5 x 30mm FA4538 3 x 12mm 427MM MW0067 **x1** wood screw x4 wood screw x2 MUD KITCHEN 5mm MUD KITCHEN

8









Thank you!

Thank you for purchasing this product.

FOR AU / NZ: IMPORTED FOR KMART STORES IN AUSTRALIA AND NEW ZEALAND

MADE IN CHINA

KEY CODE: 43298112

Product Batch No is



Mookie. Flitwick, Beds.

Please email: help@mookie.co.uk or contact our helpline on +(44) (0) 1525 722769 9am - 5pm Mon-Fri

Mookie France Espace Mistral B, 375 avenue du Mistral, 13600 La Coitat, France ina