

Single Arm Monitor Mount

Operating instructions


Includes:

- › single arm monitor mount
- › assembly pack
- › user manual





Warning Statements







- › Prior to the installation of this product, the installation instruction must be read and completely understood. Failure to do so may result in personal injury, property damage or voiding of factory warranty.
- › Do not install on a structure that is prone to vibration, movement or chance of impact. Reinforce the structure as required before installation.
- › The desk clamp can support a maximum thickness of 10cm. Confirm the desk edge before installation.
- › Do not exceed the weight limitation of the mount. Exceeding the limitation may affect the functionality of the product, or result in serious personal injury and/or property damage.
- › Never operate the mount if parts are missing or damaged. Contact your local service center for warranty service.




Arm spring back may occur upon release of cable tie. Please hold the folded arm tightly and open it slowly when taking it from the packaging and removing the tie on it. Proper handling must be taken into consideration. Failing to do so may lead to physical injuries.

Hardware Kit Content




ITEM	DESCRIPTION		QTY
W-A	M4 x 12 Bolt		4
W-B	M4 x 30 Bolt		4
W-C	M6 x 12 Hex Screw		3
W-D	4mm Hex		1
W-E	5mm Hex		1
M-A	12 x 5.8 x 16 Spacer		4


Grommet Installation



NOTE: If your desk has an existing grommet hole, please install directly. If there is no existing grommet hole, make a mark on your mounting surface, and use a drill to drill a hole (40-60mm) in the mounting surface.

Desk Clamp Installation







NOTE: Adjust the desk clamp clamping range using the adjustment hole. Position the clamp to the required thickness of the desktop (see Figure 1).

Monitor Mount Installation

Flush Surface Installation

Loosely insert the upper two screws (W-A). Leave some space and hang the monitor on the head plate (see Figure 2).

Insert the lower two screws (W-A) and fasten the upper two screws (see Figure 3).



Recessed Surface Installation

Place spacers (M-A) between headplate and monitor. Loosely insert the upper two screws (W-B). Leave some space and hang the monitor on the head plate (see Figure 4).

Place spacers (M-A) between headplate and monitor. Insert the lower two screws (W-B) and fasten the upper two screws (see Figure 5).




Figure 4




Figure 5

Adjusting the Monitor Mount

- › Push the arm downward to a horizontal position for easy adjustment (see Figure 6).
- › Using a hex wrench (W-E), adjust tension by turning the screw clockwise (tighten) or counter clockwise (loosen) depending on your monitors weight (see Figure 7).
- › Using a hex wrench (W-E), adjust screw to secure the monitor mount to the desired tilting position (see Figure 8).
- › Insert cables into cable holders (see Figure 9). Allow slack in the cables to cater for free motion of the mount.




Figure 6




Figure 7




Figure 8





Figure 9



NOTE: Positioning arm in other direction during adjustment might cause difficulties. Keep horizontal orientation while adjusting



12 Month Warranty

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations for instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expenses incurred in returning this product can be addressed to the respective Customer Services Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

MADE IN CHINA

CUSTOMER SERVICE:

KMART AU: 1800 124 125

KMART NZ: 0800 945 995

TARGET AU: 1300 753 567