

2.13M (7FT) CHRISTMAS TREE

CASHMERE SPRUCE - TREE F

43307883




Contents:

A Tree Top

B Upper Body

C Lower Body

D Metal Stand



Instructions

- 1) Carefully insert the bottom of tree section C into the tree stand . Make sure the pole is fully inserted into the stand and screws are tightened.
- 2) Insert Section B into Section C then secure into stand
- 3) Insert Section A into Section B
- 4) Lower all main branches on the bottom level and position so they are parallel to the floor, shape as desired.
- 5) For a better result, straighten and separate all the small branches.
Then, bend slightly upward in a 'V' shape to match the rest of the tree.

Warnings:

- 1) This product is for indoor use only.
- 2) Keep product away from fire and other heat sources
- 3) Recommend saving instructions for future reference.

Packaging Up and Storage Tips

- 1) Remove all lights and ornaments.
- 2) Remove sections as places, Section A and Section B.
- 3) Unscrew the tree stand from Section C before removing it from stand.
- 4) Each tree section, the branches should be pressed against the stem before placing in carton.
- 5) Pack carton and store in a dry and damp free area.
- 6) Do not place product in direct sunlight or in an area where temperatures exceed 40 degrees.

Made in China