





ASSEMBLY OPTIONS OF THE TRACKS



anko INSTRUCTION MANUAL
MOTORISED TRAIN SET

3Y+



i Read the following instructions for use carefully.

Technical data

Power supply battery:
KC#/ Model number 43317776
BATCH CODE 34/23
2x 1,5V LR03, AAA

CAUTION: BATTERY INSTALLATION BY ADULT REQUIRED.

WARNING: STRANGULATION HAZARD- LONG CORD. NOT SUITABLE FOR CHILDREN UNDER 3 YEARS.

WARNING: CHOKING HAZARD - SMALL PARTS. NOT FOR CHILDREN UNDER 3 YEARS.



WARNING: BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY (+ AND -). DO NOT MIX DIFFERENT TYPES OF BATTERIES OR NEW AND USED BATTERIES. NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED. RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED BY ADULT. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED. REMOVE BATTERIES FROM THE TOY WHEN NOT IN USE FOR EXTENDED TIME OR WHEN BATTERIES BECOME EXHAUSTED. BATTERY INSTALLATION BY AN ADULT IS REQUIRED. DISPOSE OF BATTERIES RESPONSIBLY. DO NOT DISPOSE OF IN FIRE.

WARNING: FOR SAFETY REASONS, REMOVE ALL TAGS, LABELS AND PLASTIC FASTENERS BEFORE GIVING THIS TOY TO YOUR CHILD.

WARNING: THIS TOY CONTAINS MAGNET OR MAGNET COMPONENTS. MAGNETS STICKING TOGETHER OR BECOMING ATTACHED TO A METALLIC OBJECT INSIDE THE HUMAN BODY CAN CAUSE SERIOUS OR FATAL INJURY. SEEK IMMEDIATE MEDICAL HELP IF MAGNETS ARE SWALLOWED OR INHALED.

ADULT SUPERVISION REQUIRED.
PRODUCT MAY VARY FROM IMAGE SHOWN.
PLEASE KEEP THE PACKAGING FOR FUTURE REFERENCE.

ASSEMBLY STEPS



ASSEMBLY STEPS

