

## **Wooden Doll House**

# **Assembly Instruction**

K: 43388196 T: 69555886


### **HARDWARE**

**WARNING**: CHOKING HAZARD – SMALL PARTS, NOT SUITABLE FOR CHILDREN UNDER 3 YEARS.


WARNING: ASSEMBLY AND DISASSEMBLY MUST BE CARRIED OUT BY ADULTS ONLY. PLEASE CHECK CONDITION OF ITEM REGULARLY, DISCONTINUE USE OF THE ITEM IF EXCESSIVE WEAR & TEAR IS FOUND.


ADULT SUPERVISION RECOMMENDED.
THIS IS A TOY, INTENDED FOR ROLE PLAY ONLY.
PRODUCT MAY VARY SLIGHTLY FROM IMAGE SHOWN.


#### **PARTS LIST**




#### **ASSEMBLY**











### ASSEMBLY


Step 5




Step 6




Step 7



Step 8



Step 9



Step 10

