

Assembly Instructions:

- 1) To charge, insert the supplied type C plug USB cable into the charging port on the edge of the base.
- 2) Only charge the table lamp with the supplied USB cable.

Cleaning & Maintenance:

- 1) Turn the appliance off before you start cleaning it.
- 2) Do not immerse the appliance in water. Clean the appliance surface with a dry cloth .
- 3) Do not use any lubricant, detergent, polishing agents, alcohol, steel wool, abrasive cleansers, chemicals or corrosive liquids on this appliance.

Battery and appliance disposal:

1. This appliance has a lithium battery. Batteries contain substances harmful to our environment, please do not dispose of the appliance containing batteries with the normal household waste, instead hand it over to an official recycling point.

2.Trouble Shooting

Problem	Possible Cause	Solution
LED Light is not bright enough or it does not turn on	The battery is running low or is out of power	Charge the appliance as guided

anko

LED MUSHROOM TABLE LAMP

K: 43396405 | T: 69317118

SLR-24900

INSTRUCTION MANUAL



Safety Instructions:

To ensure proper operation of this appliance, please read this instruction manual carefully before you use the appliance and save it for further reference.

⚠ WARNING

- Check the appliance before you use it, do not use the appliance if it has any crack, gap or any other damage.
- Do not attempt to repair, disassemble, or modify the appliance by yourself to avoid accidents.
- The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.
- For indoor use only.

⚠ CAUTION

- This appliance has a lithium battery. Do not place or store the appliance for long periods of time in a hot or humid environment. If you do not intend to use the appliance for a long time, store the appliance after it is fully charged.
- This appliance contains battery and LED lights that are non-replaceable.
- Ensure charging adapter used is compatible with a 5VDC SELV 1A, 5W rating.

Specifications:


- Charging Voltage / Current: 5V $\overline{\text{---}}$ / 1000mA Max. 5W
- Type of Battery: Li-ion 3.7V 2000mAh
- Ta: 25°C

Remote control parameter

- 2 * 1.5V AAA batteries required (batteries not included)

Product Description:

- ① Dimmable touch plate
- ② Charging port
- ③ Brightness adjust
- ④ ON/OFF switch
- ⑤ Colour selecting area
- ⑥ Colour flashing
- ⑦ Gradient colour changing
- ⑧ Type-C USB cable



Using the Appliance:

For better use experience, please read below instructions carefully:

1. This appliance needs to be charged if the light ray is not bright enough. Please use 5VDC SELV 1A 5W adaptor(not included) to charge.
2. Charging the appliance takes about 5 hours, and it can be used continuously for more than 6 hours for the most bright status.
3. The charging indicator light (at the bottom edge of the table lamp) will be green while the table lamp is charging and after being fully charged, the indicator light will be off.
4. Touch the top dimmable touch plate to turn on the light. Sequentially short touch the plate to change different colour and mode. Long press the plate 3 seconds to turn off the light.
5. Using remote control also can control the light. There are multiple modes, colours and function by using remote control. Please don't forget to buy 2 pcs 1.5V AAA batteries for the remote control using.