


Pet Timer Dual Feeder

- Instruction -

PET TIMER DUAL FEEDER



HOW TO USE




1. Align the arrow on the dial with the arrow on the feeder to open the feeder.



2. Fill each bowl with dry or wet food



3. Close the lids. Set the timers by turning the dial to the number of hours between now and when you want your pet fed. For example, if it's 9 AM and you set one dial to 3 and one to 8, then the corresponding lids will open at 12 PM and 5 PM.



PRODUCT MAY VARY SLIGHTLY FROM IMAGE SHOWN. PLEASE KEEP PACKAGING FOR FUTURE REFERENCE. FOR YOUR PET'S SAFETY, INSPECT REGULARLY AND REMOVE IF DAMAGED.

KEYCODE: 43423194

WARNING: BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY (+ AND -). DO NOT MIX DIFFERENT TYPES OF BATTERIES OR NEW AND USED BATTERIES. NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED. RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED UNDER ADULT SUPERVISION. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED. REMOVE BATTERIES FROM THE TOY WHEN NOT IN USE FOR AN EXTENDED TIME OR WHEN BATTERIES BECOME EXHAUSTED. BATTERY INSTALLATION BY AN ADULT IS REQUIRED. DISPOSE OF BATTERIES RESPONSIBLY. DO NOT DISPOSE OF IN FIRE.