COSMETICS

12 Month Warranty
Thank you for your purchase.
Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendation instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

For New Zealand customers, this warranty is in addition to statutory rights

observed under New Zealand legislation.
We will provide you with your choice of a refund, repair(where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period.

The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident misuse abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Contact for Kmart purchases Contact for Target purchases

Kmart Australia Ltd. Kmart Australia Ltd. C/-Customer Service Centre 690 Springvale Road, Mulgrave Vic 3170 Customer Service:1800 124 125 (Australia) or 0800 945 995 (New Zealand) or via Customer Help at kmart.com.au

Target Australia Pty Ltd C/-Customer Service Centre 2 Kendall Street. Williams Landing. Vic 3027 Customer Service:1300 753 567 Or via Customer Help at target.com.au/help/contact-us

WARNING Do not dispose of unit in fire or water. Never attempt to disassemble and reassemble. Waste WARNING Do not dispose of unit in the or water. Never attempt to disassemble and reassemble, Wastel electrical products build not be disposed or with trousched visual pelaser recycle where facilities east, extended to the control of the disposed or with the control of the disposed or the control of the dispose

LED BEAUTY HARD CASE Instruction Manual

>Cosmetic Case >USB-Type C cable



K:43-430-673 | T:69-729-003 Model No.: 200177



Product overview:





How to use this beauty hard case:

- 1. Open the latch on both sides.
- 2. Peel off the plastic film from the mirror before use.
- 3. Connect the USB-Type C cable to a power bank or wall adapter.
- 4. Once connected the power, short touch the switch on the mirror to control the light. Turn on and off the light and change the light mode.
- 5. Long press and hold the button to adjust the brightness of the light.

Specifications:

Size:

30*26*10cm

Color:

Material:

ABS+Iron+glass+aluminum+PVC+copper

Light:

50pcs warm white leds +50pcs cold white leds

Lighting:

Warm white-cold white-nature light

Input:

5V DC 1.5A

Warning:

- 1. Use a dry microfiber cloth to clean the case.
- 2. Operate and store carefully to ensure the product does not incur damage by being dropped
- 3. Do not leave the product in excessive heat or high temperatures as it can cause the product to malfunction
- 4. The strip light is non-replaceable.
- 5. For indoor use only.
- 6. The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.
- 7. 5V DC SELV adaptor(not include).

FRONT

BACK