

anko

K: 43467433 | T: 70179453 (Model: JLR-79396-B)

Desk Lamp Caddy Black Rechargeable

User Manual





Thanks for purchasing our products. In order to ensure that you can fully understand, install and use this product please read the instructions carefully, please keep it properly after reading for future reference.

Warning:

In order to prevent accidents threatening personal safety such as lamp damage, falling, electric shock and fire, please strictly install and use according to the instructions, and do not modify lamps and replace parts by yourself.

1. Do not use the power supply beyond the rated voltage range (Rated Voltage 5V, current 1A). (If it is used outside the rated voltage range for a long time, the lamp may be damaged.)
2. Lamps shall not be placed in unstable places.
3. Lamps shall not be installed above high-temperature objects or in humid places. (Do not install it above the stove, gas and exhaust funnel to prevent damage.)
4. Lamps shall not be connected in series with other electrical appliances, and cannot be used in parallel with dimmers.
5. When checking and repairing lamps, please entrust electrical professionals to operate. (Non-professional personnel are prone to danger during construction.)
6. In case of abnormal phenomenon of lamps, the power supply shall be cut off quickly and contact the sales store. (The corresponding product model shall be provided during maintenance, and refer to the display content of the lamp body.)
7. The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.
8. Use 5VDC 1A 5W SELV adaptor for charging luminaire.
9. For indoor use only.
10. This appliance contains batteries that are non-replaceable.
11. Maximum loading on two spacing is 0.23kg totally.

Function description

1. Control mode: short press  to change the color mode and long press  to adjust light brightness.
2. Charging time: it needs to be charged for about 3 hours without turning on the light
3. Charging method: connect the USB cable to the USB port of the computer or use the DC5V charger for charging, the indicator light displays red when charging, and turns green when fully charged.
4. In the process of use, when the brightness of the LED lamp is dim, the battery tends to be fully discharged Please charge the lamp in time.
5. When there is no response to the touch switch, connect the charging line for charging first, use it after fully charged.

Use and maintenance of lamps

1. Adjust the irradiation angle and scope according to the use needs
2. Please keep the surface of transparent lampshade clean to avoid affecting the lighting effect of lamps. If the transparent cover is stained with dust, gently wipe it off with a clean flannelette.
3. Please do not use alcohol, gasoline and other chemicals to wipe the lamps, otherwise the lamps may change color or be damaged.
4. It is not allowed to change the lamp structure at will, the manufacturer shall not be responsible for any lamp damage and personal injury caused by improper use or self - changing products.
5. Do not use a charger that exceeds the rated input current and voltage to charge the lamps. If the lamps are damaged due to overload, the manufacturer will not be responsible.
6. Flexible neck for easy adjustment (as below photo showing)



Product components

Desk lamp Caddy Black Rechargeable x 1

User manual x 1

1M USB Micro cable x1

Product specification:

Keycode	43467433
Product Name	Desk Lamp Caddy Black Rechargeable
Power Supply	DC 5V/1A
Battery Capacity	800mAh

Product Features:

2. Dual pen cup with phone holder
3. 3 lights settings, natural, warm, cool
4. Flexible stem

12 Month Warranty

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty.

This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Contact for Kmart purchases	Contact for Target purchases
Kmart Australia Ltd. C/- Customer Service Centre 690 Springvale Road, Mulgrave Vic 3170 Customer Service: 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or via Customer Help at kmart.com.au	Target Australia Pty Ltd C/- Customer Service Centre 2 Kendall Street, Williams Landing, Vic, 3027 Customer Service: 1300 753 567 or via Customer Help at target.com.au/help/contact-us

135 mm

90 mm