




Combination lock
is set to 0-0-0 by
default. Please see
manual within case
for instructions on
how to change the
combination.

70x100mm

TSA-Accepted Luggage Locks

- Customer Notice: Using this *Travel Sentry*® Approved lock allows your luggage to be unlocked and inspected by security authorities without damage.
- For more information on the *Travel Sentry*® Approved override system, please visit www.travelsentry.org



TSA15023

INSTRUCTIONS

The original number is 0-0-0. To set your personal combination, follow these steps:

1. Put the dials at its original numbers 0-0-0;
2. Press down the reset button(a) with a tool until hear the "click" sound.
3. Set your combination by turning the dials(b), for example 8-8-8.
4. Push the button(c) towards to the direction of arrow and the reset button(a) will be back when you hear the "Click" sound.

Now you have finished setting your personal combination.

Please remember your personal combination by heart-You will not be able to open or reset without the correct combination.

Please repeat the above steps to reset the numbers.

WARNING: If the cylinder is opened, pls pay attention to lock it again by turning it to the red dot position by the direction of the arrow (Any tool which can be inserted in the cylinder is OK)

