

# Dual Section Pedal Mop Set

K:43533220 T:70902563

Clean water chamber  
Dirty water chamber


Including:

4 x Handles

2 x Microfiber mop heads

1 x Clean water chamber

1 x Dirty water chamber



## BETTER CLEANING + SPIN MOP USE MANUAL

- Remove clean water chamber from the bucket
- Remove the fill cap and fill chamber with water. Optional: Add your favorite cleaning solution to water
- After filling, ensure to close the fill cap and then place clean water chamber back into bucket.
- The clean water will be released automatically to rinsing chamber. And the water will automatically stop filling when it reaches the right level.
- Place mop inside rinsing chamber. Twist mop to wet/rinse the mop head.
- Then place the wet mop inside wringer.
- Push pedal to wring out water to preferred moisture level. At the same time to hold the handle vertically to allow mop to spin.
- Mop floor and repeat steps 5-7 as you needed.
- After use, pour out the dirty water through the drain

### Advantage

- 6.5L of continuously clean water - with dual-chamber bucket technology featuring separated clean and dirty water tanks, mop with a continuous flow of clean water; the clean water tank holds up to 6.5L of clean water!
- Effortless wringing with pedal - the innovative push pedal replaces wringing by hand and allows efficient moisture control the more pedal kicks, the drier the result.
- Always clean water double chamber bucket with separate tanks for clean and dirty water - lift lever for continuous flow of always clean water
- Microfibre cleaning - the microfibre mop head allows excellent dirt absorption, so that all hard floors (wood, laminate, tiles, vinyl and more) shine clean and streak-free in no time

### 100% Separation of clean & dirty water

