anko



Assembling the mop

Before first use, remove all of the packaging from the components.

To assemble the handle, remove the poles and mop head from the bucket.

STEP 1: Insert the small end of pole (2) into the mop head (5) and twist in a clockwise direction until the pole is secure.

STEP 2: Take both poles (3) and insert into each other, twisting in a clockwise direction until secure.

STEP 3: Take the combined poles and insert into the free end of pole (2), twisting in a clockwise direction until the pole is secure.

STEP 4: Insert pole (4) into the free end of the combined poles and twist in a clockwise direction until the pole is secure.

STEP 5: To assemble the microfibre mop head, insert into the mop head until it clicks and is fully secure.

Using the spin mop

STEP 1: Fill the mop bucket with warm water; do not overfill above the bottom of the wringing basket. Only use the recommended amount of detergent or disinfectant, according to the manufacturer's instructions.

STEP 2: Using the carry handle, move the mop bucket to the desired location and place on an even surface.

STEP 3: Take the assembled mop and plunge into the water in the mop bucket. Once wet, place the mop head into the wringing basket, ensuring the entire microfibre head fits in.

STEP 4: To wring out the microfibre head, push down on the pedal with your foot whilst keeping hold of the mop handle. The wringing basket will spin as the pedal is pushed down to wring out the mop.

STEP 5: Repeatedly push down on the pedal until the microfibre head has been sufficiently wrung, then proceed to mop the floor surface.

STEP 6: Repeat the plunging and wringing process as required.



CAUTION: Do not fill the bucket with hot or boiling water. Do not fill the bucket above the bottom of the wringing basket. Keep out of the reach of children. Not suitable for use with bleach.

Changing the mop head

STEP 1: Place the mop head on the ground, with the microfibre head facing downwards.

STEP 2: Stand on the microfibres of the microfibre head near its centre to hold it in position whilst pulling the mop head away until it clicks.

STEP 3: Replace the microfibre head by inserting it back into the mop head until it clicks and is fully secure.