

ASSEMBLY INSTRUCTIONS

K: 43540341 | T: 70956375 Shower Curtain Tension Rod

CARE INSTRUCTIONS: Extension telescopic rod can be applied on all smooth and rough surfaces like wallpaper, paint wall, tile wall, wooden frame, etc. Check and tighten all parts regularly. Wipe clean with a soft damp cloth. For indoor and domestic use.

WARNING: Only use on firm and flat surface. Ensure the product is perpendicular to the surface, ensure the rod is parallel to the floor, load it evenly. Adult assembly required. Failure to follow these warnings could result in serious injury.

MAXIMUM LOADING WEIGHT: 3kg

EXTENSION RANGE: 120-200cm

