

hs2025-02-27

105mm

105mm

aniko

Instruction manual

K: 43-542-079 | T: 75-961-577

Model No.: 205079

SENSOR MOTION DOWN LIGHT

IMPORTANT SAFETY INSTRUCTIONS:

The following safety precautions should always be followed, to reduce the risk of electric shock, personal injury or fire. It is important to read all of these instructions carefully before using the product, and to save them for future reference or new users.

WARNING:


1. Read this user manual thoroughly before first use and pass it on with the product.
2. LEDs are not replaceable. When it reaches its end of life, the whole light shall be replaced.
3. Do not stare into the LED beam.
4. The product is intended to be used in moderate climates only. Do not use in hospital or very humid climates.
5. Do not move the product from cold into warm environments and vice versa.
6. The use of accessories and parts not specifically recommended by the manufacturer may cause injuries or damages and will result in forfeiture of the warranty.
7. If the product shows damages, do not use it any longer and have it repaired by a qualified technician, or contact our customer service department. Do not disassemble the product, and do not try to repair it yourself.
8. Remove the batteries from the product before disposal.
9. Do not attempt to open the LED module to avoid damage.
10. The battery in the product can be replaced but cannot be charged.
11. Children must not use this product without adult supervision.
12. Do not expose the product to fire or high temperatures over 45°C.
13. Keep away from water, liquid or wet areas.
14. Use a dry cloth to clean the product. Do not use chemicals on the product.
15. Do not place the product in direct sunlight, heat or under the weather.
16. When the unit is not in use, make sure it is correctly turned off and stored in a cool dry place.
17. When disposing of the product, do so responsibly following local government requirements.
18. The light source of this luminaire is not replaceable when the light source reached its end of life, the whole luminaire shall be replaced.

WARNING: READ AND FOLLOW ALL ABOVE INSTRUCTIONS CAREFULLY. DO NOT DROP OR APPLY EXCESSIVE FORCE TO THIS PRODUCT. DO NOT EXPOSE TO HIGH TEMPERATURES. HARMFUL USE OR HANDLING OF THIS PRODUCT MAY RESULT IN FIRE OR EXPLOSION CAUSING SERIOUS INJURY OR PROPERTY DAMAGE.

Operating manual

Receder: Product only works for dark area.

1. Slide down the battery cover from the back of light.




2. Insert 3 x AAA batteries into the compartment and make sure flat end of battery can contact spring. Then install the cover back. When in dark area, once a person or animal enters the sensing area, the light will turn on for around 18-23.5 and then turn off automatically.



3. Light installation

WARNING: ENSURE SECURE ATTACHMENT TO WALL. CONSULT A DRY EXPERT IF REQUIRED.


- Option 1:** A) Use the included adhesive pad to fix the light. Peel off the label from one side and apply the adhesive to the back of plate.
B) Peel off the other side and stick the light to an appropriate place.



- Option 2:** Mount the light by screw. Find a desired location and fix up the mounting plate with wall. Mark the holes by a pencil. Create holes by using a 3.5/4-8 bit (if mounting on drywall, use the plastic anchors included). Before screw the mounting in, use a hammer to tap the plastic anchors into marked holes.



You may need to change the batteries if the light does not work or malfunction. Slide up the light and remove from the mounting plate, after battery installation, you can slide down to install the light on mounting plate.



Noted: If fixed in a straight line toward the light sensor, it may not work.

Battery Installation:

Each product requires 3 x 3.5 V AAA batteries (Not included).
Battery installation by an adult is required.

BATTERY WARNING:

Batteries are to be inserted with correct polarity.
Do not mix different types of batteries or new and used batteries.
The supply terminals are not to be short-circuited.
Remove batteries from the product when not in use for extended times or when batteries become exhausted.
Dispose of batteries responsibly.
Do not dispose of in fire.

front

back