



Instruction manual

K: 43-545-032 | T: 70-969-382

Model No: DY2410171

MOTION SENSOR LED LIGHT BAR

IMPORTANT SAFETY INSTRUCTIONS:

The following safety precautions should always be followed, to reduce the risk of electric shock, personal injury or fire. It is important to read all of these instructions carefully before using this product, and save them for future reference or new users.

WARNING: FOR INDOOR USE ONLY. READ AND FOLLOW ALL ABOVE INSTRUCTIONS CAREFULLY. DO NOT DROP OR APPLY EXCESSIVE FORCE TO THIS PRODUCT. DO NOT EXPOSE TO HIGH TEMPERATURES. IMPROPER USE OR HANDLING OF THIS PRODUCT MAY RESULT IN FIRE OR EXPLOSION CAUSING SERIOUS INJURY OR PROPERTY DAMAGE.

Operating manual:

1. Remove the isolated label before use.
2. Product only work in dark area, product will turn on about 30 seconds when detect a person or animal enters the sensing area. Detected distance about 3 meters.

3. Before adhering strip lights, clean the surface of the area you will be placing the light on. It is recommended to apply your light bar on smooth stable surfaces. It should not be placed on rough, textured or painted wall surfaces or any surfaces that can bend or move.
4. Peel off the tape on the bottom and stick on a smooth, tidy surface or hook and loop on a hook (not included).

Battery installation:

Requires: 4 x 1.5V AAA batteries (included).

Battery installation by an adult is required.

Battery Warning:

- Batteries are to be inserted with correct polarity.
- Do not mix different types of batteries or new and used batteries.
- The supply terminals are not to be short-circuited.
- Remove batteries from the product when not in use for extended time or when batteries become exhausted.
- Dispose of batteries responsibly.
- Do not dispose of in fire.

**WARNING: ENSURE SECURE
ATTACHMENT TO WALL. CONSULT
A DIY EXPERT IF REQUIRED.**