

Assembly Instructions

K: 43546084 | T: 70975093 ISLA STORAGE CABINET

CARE INSTRUCTIONS:

Wipe clean with a dry cloth. Never use scourers, abrasives or chemical solvents. Keep away from moisture and direct sunlight. Store in a dry place, for indoor use only.

















WARNING:

Do not stand, sit, or lean on the unit. Ensure this unit is used only on a flat surface. Do not use this unit unless all bolts and screws are securely fastened. Do not place hot objects, such as coffee cups, directly on the surface of this furniture item. This item is for storage purposes only. It contains small parts, should be properly fastened, and must be assembled by an adult. Failure to follow these warnings could result in serious injury.















MAXIMUM SAFE LOAD: 5kg for each shelf.


1


Hardware List



	A	6x35mm	15pcs		B	15x10mm	15pcs
	C	6x30mm	14pcs		D	5x38mm	20pcs
	E	M3mm	1pc		F	M4mm	1pc
	G	M6x12mm	8pcs		H		4pcs
	I		4pcs		J		2pcs
	K	3.5x14mm	29pcs		L	M4x35mm	5pcs
	M		1pc		N	6x30mm	1pc
	O		2pcs		P		8pcs

2

					
①	1pc	②	2pcs	③	2pcs
					
④	1pc	⑤	1pc	⑥	1pc
					
⑦	1pc	⑧	1pc	⑨	1pc
					
⑩	1pc	⑪	2pcs	⑫	1pc
					
⑬	1pc	⑭	1pc		




STEP 1  A×8




STEP 2

● B×4 — C×2





STEP 3




STEP 4

 B×4
  C×2




STEP 5

 C×4
  L×4






STEP 6





STEP 7

A×4	B×4	C×4	J×2	K×4
-----	-----	-----	-----	-----




STEP 8

- A×3
- B×3
- C×2





STEP 9

- G×8





x2




STEP 10




STEP 11




STEP 12





STEP 13




Assemble fitting 14 after moving the product over the toilet.



✓ K×4




✓ K×8



STEP 16

L×1 M×1 N×1 K×1



⚠ WARNING




Children have died from furniture tipover.

- ALWAYS secure it with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV on this furniture



This is a permanent label. Do not remove!

TOPPLING FURNITURE WARNING:

- **ALWAYS secure it with an anchor device.**
- **Please seek professional advice if you are in doubt of what fixing device to use.**
- **Regularly check that anchors are securely maintained.**
- **Use safety drawer locks to prevent children climbing.**
- **Stability of tall items may be affected by thick pile carpet or uneven floors .**
- **Do not place unanchored televisions on furniture .**

CAUTION: for your safety when attaching the anchor fixings, please note the following:

- **Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson).**



WARNING: PLEASE SECURE YOUR FURNITURE WITH THE SUPPLIED WALL FIXING. SCAN THE CODE FOR MORE INFORMATION.

