## Assembly Instructions K:43546558 | T:70979305 ISLA BATHROOM CABINET


## CARE INSTRUCTIONS:


Wipe clean with a dry cloth. Never use scourers, abrasives, or chemical solvents. Keep away from moisture and direct sunlight. Store in a dry place, for indoor use only. **WARNING:** 


Do not stand, sit, or lean on the unit. Ensure this unit is used only on a flat surface. Do not use this unit unless all bolts and screws are securely fastened. Do not place hot objects, such as coffee cups, directly on the surface of this furniture item. This item is for storage purposes only. It contains small parts, should be properly fastened, and must be assembled by an adult. Failure to follow these warnings could result in serious injury.


MAXIMUM SAFE LOAD: 10kg for top, 3kg for each shelf.


1 Hardware List							2	
	A	6x35mm	6pcs		В	15x10mm	6pcs	
	С	6x30mm	12pcs		D	5x30mm	4pcs	
0	E	M6x35mm	8pcs	0	F	M6x25mm	8pcs	① 1pc ② 1pc ③ 4pcs
	G		1pc		н		8pcs	
٥٠٦	1		2pcs		J		1pc	④ 2pcs ⑤ 1pc ⑥ 1pc
<b>∲</b> )>	к	3.5x14mm	10pcs	()	L	M4x35mm	8pcs	
0 0	M		2pcs		N	6x30mm	2pcs	
	0	M4mm	1pc		Р	M3mm	1pc	⑦ 1pc ⑧ 2pcs ⑨ 1pc
					1			
								10 1pc 1 2pcs






















- ALWAYS secure it with an anchor device.
- Please seek professional advice if you are in doubt of what fixing device to use.
- Regularly check that anchors are securely maintained.
- Use safety drawer locks to prevent children climbing.
- Stability of tall items may be affected by thick pile carpet or uneven floors .
- Do not place unanchored televisions on furniture .

**CAUTION:** for your safety when attaching the anchor fixings, please note the following:

• Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson).

