

Assembly Instruction

43554072 BURLEIGH CHEST OF DRAWERS

CARE INSTRUCTIONS:





















WIPE CLEAN WITH A SOFT DAMP CLOTH.DO NOT USE ABRASIVE MATERIALS AND SOLVENTS.CHECK AND TIGHTEN ALL PARTS REGULARLY.DO NOT PLACE HOT ITEMS SUCH AS COFFEE CUPS DIRECTLY ON THE SURFACE.KEEP AWAY FROM WATER AND DIRECT SUNLIGHT.STORE IN A DRY PLACE.FOR DOMESTIC USE ONLY.FOR INDOOR USE ONLY.A MILD ODOUR MAY BE PRESENT WHEN FIRST OPENING THIS CARTON.SIMPLY ALLOW TO AIR OUTSIDE AND THIS WILL FADE.



WARNING:

DO NOT STAND OR SIT ON THIS UNIT.DO NOT USE THIS UNIT UNLESS ALL BOLTS AND SCREWS ARE FIRMLY SECURED.DO NOT KNOCK OR DRAG THIS UNIT.USE ONLY ON A FLAT SURFACE. LOAD DRAWER EVENLY TO PREVENT FROM TIPPING OVER. THIS PACKAGE CONTAINS SMALL PARTS AND SHARP POINTS. KEEP AWAY FROM CHILDREN AND BABIES. ADULT ASSEMBLY REQUIRED. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.


MAXIMUM SAFE LOAD: 15KGS FOR TOP, 7.5KGS FOR EACH DRAWER.

Hardware List

	A	6x35mm	31pcs	CR  DR 		300mm	3pcs
	B	15x10mm	31pcs	CL  DL 		300mm	3pcs
	C	8x30mm	8pcs		J		8pcs
	D	6x40mm	4pcs		K	3x16mm	8pcs
	E	4mm	1pc		L	4x14mm	2pcs
	F	3x12mm	36pcs		M		4pcs
	G	4x18mm	3pcs		N		2pcs
	H		3pcs		O		2pcs
	I	6x30mm	3pcs		P	4x35mm	20pcs

















Tools Required(Not Provided)






Do not tighten the screws fully during assembly.
Fully tighten screws after the final assembly steps.

Part List

							
①	1 PC	②	1 PC	③	1 PC	④	2 PCS
							
⑤	1 PC	⑥	2 PCS	⑦	1 PC	⑧	4 PCS
							
⑨	3 PCS	⑩	3 PCS	⑪	3 PCS	⑫	3 PCS
							
⑬	3 PCS	⑭	3 PCS				



Step 1:

Ax12
 Fx18 3x12mm
 CL x3
 CR x3





Step 3:

B x6





Step 2:

B x6




Step 4:




C x4 8x30mm
 D x4 6x40mm
 E x1





Step 5:




Step 7:



Step 6:




Step 8:







Step 9:

 P x 18
4x35mm





Step 11:

 B x 15  I x 3
6x30mm




Step 10:



 Ax15  Gx3
4x18mm  Hx3





Step 12:



Step 13:



Step 14:



TOPPLING FURNITURE WARNING:

- **ALWAYS** secure it with an anchor device.
- Please seek professional advice if you are in doubt of what fixing device to use.
- Regularly check that anchors are securely maintained.
- Use safety drawer locks to prevent children climbing.
- Stability of tall items may be affected by thick pile carpet or uneven floors .
- Do not place unanchored televisions on furniture.

CAUTION: for your safety when attaching the anchor fixings, please note the following:


- Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson).



WARNING: PLEASE SECURE YOUR FURNITURE WITH THE SUPPLIED WALL FIXING. SCAN THE CODE FOR MORE INFORMATION.



! WARNING



Children have died from furniture tipover.

- ALWAYS secure it with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV on this furniture



This is a permanent label. Do not remove!