
210mi

anko

Solar Camping Lantern Instruction Manual

Keycode: 43-564-682



Product Specifications:


Dimensions: 10cm(H) x 10.5cm(Dia.)

Input: 5V/0.5A Led power: 2W

Battery Capacity: 1200mAh

Operating Instructions:

- 1. Rotate the switch to the right until you hear a click. This will turn the light on.
- 2. Continue rotating the switch to the right to gradually increase the brightness.
- 3. To dim the light, rotate the switch to the left.
- 4. Keep rotating the switch to the left until you hear a click. This will turn the light off.



WARNING: SOLAR CHARGING IS FOR EMERGENCY USE ONLY. DO NOT DISASSEMBLE THE LIGHT. KEEP AWAY FROM FIRE. TO AVOID ELECTRIC SHOCK. DO NOT EXPOSE TO WATER OR RAIN. AVOID CHARGING FOR EXTENDED PERIODS, LEAVING IT UNDER DIRECT SUNLIGHT. OR EXPOSING IT TO ENVIRONMENTAL TEMPERATURES OVER 45°C.

MADE IN CHINA

CUSTOMER SERVICE: KMART AU: 1800 124 125 KMART NZ: 0800 945 995 TARGET AU: 1300 753 567