








## EVENT DISPLAY METAL GRID STAND (Model No.: DE24129 Keycode: 43573066)




Overall Size: 45/Wx45/Dx200/Hcm

### Contents:


<p>A.</p>  <p>Metal stand x2</p>	<p>B.</p>  <p>Joint part A x1</p>	<p>C.</p>  <p>Joint part B x1</p>
<p>D.</p>  <p>Joint part C x1</p>	<p>E.</p>  <p>Fixing screw x6</p>	<p>F.</p>  <p>Fixing rope x2</p>

### Instructions:


#### Step 1.



#### Step 2.



## Step 3.



## Warnings:

These instructions are for your safety. Please read through them thoroughly before use and retain for future reference.

Optional for extra stability

Tie ropes to screws / nails (not included) attached to nearby fixed wall OR  
Tie ropes to nearby fixed poles

## Step 4.

