Wooden Stitch Ice Cream Cart Assembly Instructions



K · 43575701

		K: 435/5/01
HARDWARE		PARTS LIST
Α	Qx39	
В	()x10	
C	(A)	3
D	⊚	
E	()	
F	© □100000000 ×2	8 x2 9 10
	s Required Concluded)	
Hexa	agon wrench (Included)	
Cros	s screwdriver (Not Included)	
	ID FOLLOW INSTRUCTIONS CAREFULLY AND KEEP URE REFERENCE.	
CARRIE	NG: ASSEMBLY AND DISASSEMBLY MUST BE DOUT BY ADULTS ONLY. ADULT SUPERVISION	
STAIRS,	MMENDED. DO NOT PLAY WITH THIS ITEM NEAR SLOPES ETC.	17
FUNCTIO	G: UNASSEMBLED PARTS CONTAIN SCREWS WITH DNAL SHARP POINTS, PLEASE KEEP UNASSEMBLED WAY FROM SMALL CHILDREN.	
AS SCRE SCREW F	N: PLEASE CHECK CONDITION OF ITEM REGULARLY, WS MAY LOOSEN WITH USE OVER TIME. TIGHTEN FITTINGS IF NECESSARY. STOP USING THIS	
JOINTS C	IT IF THERE IS ANY LOOSE OR MISSING FASTENERS, DR BROKEN PARTS.	
USE THE THE PRO ARE FIRM REGULA	NG: DO NOT STAND ON THE PRODUCT. DO NOT E PROUDCT AS A STEP LADDER. DO NOT USE DDCUT UNLESS ALL BOLTS, SCREWS AND KNOBS MLY SECURED. CHECK AND TIGHTEN ALL PARTS IRLY.FAILURE TO FOLLOW THESE WARNINGS	20 x3 22 28 28 28
	RESULT IN SERIOUS INJURY. IM LOAD LIMIT FOR TABLE: 5KGS	


THIS IS A TOY, INTENDED FOR ROLE PLAY ONLY.


MADE IN CHINA

ASSEMBLY

Step 1

Step 2








Step 3

Step 4



Step 5

