


anko

Cat Scratcher House



Contents



A. Bottom & Side paper x 1 pc	B. Side papers x 2 pcs	C. Second floor side paper and roof x 2 pcs	D. Top paper x 1 pc
E. Paper Scratcher x 1 pc			

Assembly Instructions


Step 1.

Connect the corners of part A and B using the cardboard tabs as below:



Step 2.

Fold parts C along the inside crease, making it a 90-degree fold:



Step 3.

Connect the second floor to your assembled structure using the cardboard tabs as shown below. When one side is finished, tuck the tabs in along the entrance holes, then place the paper scratcher part E into the bottom of your assembled structure. Finally, complete the assembly of the other side.



Step 4.

Connect part D to the assembled scratcher using the cardboard tabs as shown below:



WARNING: Pet toy – Not intended for children.

It is the responsibility of the pet owner if this toy is suitable for their pet's style of play.

No pet toy is indestructible and can be damaged during play.

For your pet's safety, inspect regularly and remove if damaged.

Always supervise your pet during play.