

285 mm


210 mm

anko


Retro BBQ

Instruction Manual

Keycode: 43-657-230 43-627-929



Oven Accessories



Parts List


1. Chimney x 1	2. Brazier x 1	3. Furnace body x 1
4. Leg tube x 2	5. Brazier x 2	6. Grill Net x 2

Screw List


A	ScrewM5 x 25		6Pcs
B	ScrewM5 x 8		6Pcs
C	Hand twist the butterfly screwM5		12Pcs

285 mm


210 mm




1. Install the leg tubes using screws A and C, as shown in the diagram.




3. Install the handle onto the top cover using screws B and C, as shown in the diagram.



2. Attach the chimney to the top cover using screws B and C, as shown in the diagram.



4. To operate: first, turn on the stove. Then place the brazier at the bottom, and finally rest the grill net on top of the stove.



5. Installation is complete. The stove is now ready for use.

WARNING: NOT TO BE USED INDOORS FOR COOKING OR HEATING. WHEN USING CHARCOAL BRIQUETTES FOR COOKING OR HEATING KEEP AWAY FROM ENCLOSED AREAS AS TOXIC CARBON MONOXIDE FUMES CAN ACCUMULATE AND CAUSE ASPHYXIATION. TO AVOID INJURY TEST TEMPERATURE OF BBQ BEFORE MOVING OR STORING. KEEP OUT OF REACH OF CHILDREN AND PETS.

MADE IN CHINA
CUSTOMER SERVICE:
KMART AU: 1800 124 125
KMART NZ: 0800 945 995
TARGET AU: 1300 753 567