

Lantern Built-in Speaker

User Manual



LIGHTING DEVICE			
LIGHT SOURCE	16pcs×SMD	POWER	3W
DIMENSIONS	21cm×11.5cm	BLUETOOTH v4.0	Max70db
WEIGHT	250g	RECHARGEABLE	USB cable included
BATTERY	2×14500 500mAh	RUNTIME	Speaker only: approximately 8 hours Lantern only: approximately 2.5 hours Speaker and lantern together: approximately 2 hours
FUNCTION	Press the switch briefly: Flame jumps. Press briefly again: Light stays on constantly. Press briefly once more: Turn off.		
	Long press the switch: Turn on Bluetooth. Long press again: Turn off Bluetooth.		
	Short press the button: Adjust the volume. Long press the button: Switch tracks.		

NOTE: TO PREVENT EYE DAMAGE, DO NOT SHINE THE LANTERN DIRECTLY INTO YOUR EYES OR INTO THE EYES OF OTHERS, INCLUDING ANIMALS. PLEASE READ ALL INSTRUCTIONS CAREFULLY AND ENSURE THEY ARE FULLY UNDERSTOOD BEFORE USING THE BLUETOOTH SPEAKER.

Bluetooth connect instructions:

Long press the power switch until the voice prompt says "Bluetooth paired."
(Bluetooth mode: FA-219)
The device is now ready to connect, and you can play music from your mobile phone, tablet, or other portable audio device.

Warning :

1. Read all instructions carefully and ensure they are fully understood before using the Bluetooth speaker and lantern.
2. Do not shine the lantern directly into eyes.
3. Do not drop the device.
4. Use only the designated charging interface. Do not charge near water or in damp environments.
5. Do not place near fire or other heat sources, as the battery may explode.
6. The battery must be recycled or disposed of according to local regulations.

Care Instructions:

Cleaning

Wipe the exterior with a soft, dry cloth.
Do not immerse in water or use harsh chemicals.

Storage

Store in a cool, dry place when not in use. Avoid direct sunlight or high humidity environments.

Battery Maintenance

Recharge periodically to maintain battery health.