


anko

Aaron 6 Drawer Chest

Instruction Manual



The photos and illustrations shown in this instruction manual are generic.

The manufacturer reserves the right to change any specification or feature without prior notice.

IMPORTANT: KEEP FOR FUTURE REFERENCE. READ CAREFULLY.

Assembly Instructions

43633074 Aaron 6 Drawer Chest

CARE INSTRUCTIONS:

WIPE CLEAN WITH A DRY CLOTH.

DO NOT USE ABRASIVE MATERIALS AND SOLVENTS.

CHECK AND TIGHTEN ALL PARTS REGULARLY.

DO NOT PLACE HOT ITEMS SUCH AS COFFEE CUPS DIRECTLY ON THE SURFACE.

KEEP AWAY FROM WATER AND DIRECT SUNLIGHT.

STORE IN A DRY PLACE. FOR DOMESTIC USE ONLY.

FOR INDOOR USE ONLY.

A MILD ODOUR MAY BE PRESENT WHEN FIRST OPENING THIS CARTON.

SIMPLY ALLOW TO AIR OUTSIDE AND THIS WILL FADE.

WARNING:

DO NOT STAND OR SIT ON THIS UNIT.

DO NOT USE THIS UNIT UNLESS ALL BOLTS AND SCREWS ARE FIRMLY SECURED.

DO NOT KNOCK OR DRAG THIS UNIT.

USE ONLY ON A FLAT SURFACE.

ADULT ASSEMBLY REQUIRED.

FAILURE TO FOLLOW THESE WARNING COULD RESULT IN SERIOUS INJURY.

LOAD DRAWER EVENLY TO PREVENT FROM TIPPING OVER.

THIS PACKAGE CONTAINS SMALL PARTS AND SHARP POINTS.

KEEP AWAY FROM CHILDREN AND BABIES.

MAXIMUM SAFE LOAD:

15KGS FOR TOP PANEL, 7KGS FOR BIG DRAWER, 5KGS FOR SMALL

DRAWER.



1 Hardware List

a		M6x35mm	54pcs	b		Ø15x9.5mm	54pcs	c		Ø6x30mm	50pcs	d		M4x30mm	36pcs
e			22pcs	f		M4x12mm	2pcs	g		M4x35mm	2pcs				


2 Parts List

① 1PC	② 1PC	③ 1PC	④ 1PC
⑤ 1PC	⑥ 1PC	⑦ 6PCS	⑧ 2PCS
⑨ 4PCS	⑩ 1PC	⑪ 1PC	⑫ 6PCS
⑬ 6PCS	⑭ 4PCS	⑮ 2PCS	⑯ 4PCS
⑰ 4PCS	⑱ 2PCS	⑲ 1PC	

PANEL LAYOUT




STEP 1




a - x 18 | c - x 22

STEP 2




a - x 2 | b - x 2 | c - x 4 | d - x 2

STEP 3




b - x 9

STEP 4





b - x 9

STEP 5




a - x 6 c - x 8

STEP 6




b - x 6 d - x 2

STEP 7




STEP 8




STEP 9


g -  x 2




STEP 10




STEP 11



STEP 12




STEP 13




STEP 14

DRAWERS X 4





STEP 15

DRAWERS X 4



STEP 16




Install the inner fixing rail to the drawer and lock the middle fixing rail in order to allow the drawer to slide open and closed.

TOPPLING FURNITURE WARNING:

- **ALWAYS** secure it with an anchor device.
- **Please seek professional advice if you are in doubt of what fixing device to use.**
- **Regularly check that anchors are securely maintained.**
- **Use safety drawer locks to prevent children climbing.**
- **Stability of tall items may be affected by thick pile carpet or uneven floors .**
- **Do not place unanchored televisions on furniture .**

CAUTION: for your safety when attaching the anchor fixings, please note the following:

- **Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson).**



Children have died from furniture tipover.

- **ALWAYS** secure it with an anchor device.
- **NEVER** allow children to stand, climb or hang on drawers, doors, or shelves.
- **NEVER** open more than one drawer at a time.
- **Place heavy items down low.**



This is a permanent label. Do not remove!



WARNING: PLEASE SECURE YOUR FURNITURE WITH THE SUPPLIED WALL FIXING. SCAN THE CODE FOR MORE INFORMATION.

