


anko

Charlie 6 Drawer Chest

Instruction Manual



The photos and illustrations shown in this instruction manual are generic.

The manufacturer reserves the right to change any specification or feature without prior notice.

IMPORTANT: KEEP FOR FUTURE REFERENCE. READ CAREFULLY.

Assembly Instructions

43633685 Charlie 6 Drawer Chest

WARNING:

DO NOT STAND, SIT OR LEAN ON THIS UNIT.

DO NOT USE THIS UNIT AS A STEP LADDER OR AS A CHOPPING SURFACE.

KEEP AWAY FROM CHILDREN AND BABIES.

ADULT ASSEMBLY REQUIRED.

USE ONLY ON A FLAT SURFACE.

DO NOT USE THIS UNIT UNLESS ALL BOLTS AND SCREWS ARE FIRMLY SECURED.

CARE INSTRUCTIONS:

TO BE ASSEMBLED ON A CLEAN, DRY AND SMOOTH SURFACE.

WIPE CLEAN WITH A SOFT DAMP CLOTH.

NEVER USE SCOURERS, ABRASIVES OR CHEMICAL SOLVENTS.

CHECK AND TIGHTEN ALL PARTS REGULARLY.

KEEP AWAY FROM MOISTURE AND DIRECT SUNLIGHT.

STORE IN A DRY PLACE.

FOR INDOOR AND DOMESTIC USE ONLY.

MAXIMUM SAFE LOAD:

25KG FOR TOP PANEL, 7KG FOR EACH DRAWER.



1 Hardware List

A		M6x35mm	54pcs	B		Ø15x9mm	58pcs	C		Ø6x30mm	48pcs	D		M4x35mm	60pcs
E			8pcs	F		M3x16mm	8pcs	G			2pcs	H			2pcs
I			4pcs	J			8pcs	K			84pcs	L		M7x70mm	2pcs
M		Ø6x50mm	2pcs	N			2pcs	CL			6pcs	CR			6pcs
DL			6pcs	DR			6pcs								


2 Parts List

① 1PC	② 1PC	③ 1PC	④ 1PC
⑤ 1PC	⑥ 1PC	⑦ 4PCS	⑧ 1PC
⑨ 1PC	⑩ 2PCS	⑪ 2PCS	⑫ 2PCS
⑬ 3PCS	⑭ 3PCS	⑮ 6PCS	⑯ 6PCS
⑰ 6PCS	⑱ 6PCS	⑲ 6PCS	⑳ 1PC

PANEL LAYOUT




x 3




x 3


STEP 1




STEP 2



STEP 3




STEP 4




B -  x 7 C -  x 2 D -  x 2

STEP 5




A - x 8

STEP 6




B - x 8

STEP 7




I - x 4 J - x 8

STEP 8




C - x 12 D - x 12

STEP 9




STEP 10




C -  x 6 D -  x 6

STEP 11




A - x 6 G - x 2 H - x 2

STEP 12




STEP 13



B - x 6 C - x 8 D - x 2


STEP 14



E - x 8 F - x 8


STEP 15

D -  x2 N -  x2




STEP 16

DRAWERS X 3




STEP 17

DRAWERS X 3



STEP 18


DRAWERS X 3



K - x 18 | DL - x 3 | DR - x 3

STEP 19


DRAWERS X 3



A - x 15 | B - x 12 | C - x 6


STEP 20

DRAWERS X 3




STEP 21

DRAWERS X 3



STEP 22



TOPPLING FURNITURE WARNING:

- **ALWAYS** secure it with an anchor device.
- **Please seek professional advice if you are in doubt of what fixing device to use.**
- **Regularly check that anchors are securely maintained.**
- **Use safety drawer locks to prevent children climbing.**
- **Stability of tall items may be affected by thick pile carpet or uneven floors .**
- **Do not place unanchored televisions on furniture .**



CAUTION: for your safety when attaching the anchor fixings, please note the following:

- **Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson).**

