


anko

# Sadie 3 Drawer Chest

## Instruction Manual



The photos and illustrations shown in this instruction manual are generic.  
The manufacturer reserves the right to change any specification or feature without prior notice.

**IMPORTANT: KEEP FOR FUTURE REFERENCE. READ CAREFULLY.**

# Assembly Instructions

## 43633760 Sadie 3 Drawer Chest

### **WARNING:**

DO NOT STAND, SIT OR LEAN ON THIS UNIT.

DO NOT USE THIS UNIT AS A STEP LADDER OR AS A CHOPPING SURFACE.

KEEP AWAY FROM CHILDREN AND BABIES.

ADULT ASSEMBLY REQUIRED.

USE ONLY ON A FLAT SURFACE.

DO NOT USE THIS UNIT UNLESS ALL BOLTS AND SCREWS ARE FIRMLY SECURED.

### **CARE INSTRUCTIONS:**

TO BE ASSEMBLED ON A CLEAN, DRY AND SMOOTH SURFACE.

WIPE CLEAN WITH A SOFT DAMP CLOTH.

NEVER USE SCOURERS, ABRASIVES OR CHEMICAL SOLVENTS.

CHECK AND TIGHTEN ALL PARTS REGULARLY.

KEEP AWAY FROM MOISTURE AND DIRECT SUNLIGHT.

STORE IN A DRY PLACE.

FOR INDOOR AND DOMESTIC USE ONLY.

### **MAXIMUM SAFE LOAD:**

**15KG FOR TOP PANEL, 7KG FOR EACH DRAWER.**



## 1 Hardware List

A		M6x35mm	33pcs	B		Ø15x9mm	33pcs	C		Ø6x30mm	27pcs	D		M4x35mm	26pcs
E			8pcs	F		M3x16mm	8pcs	G			2pcs	H		M4x12mm	2pcs
I			1pcs	J		M7x40mm	8pcs	K		M3.5x12mm	42pcs	L			2pcs
CL			2pcs	CR			2pcs	DL			2pcs	DR			2pcs

## 2 Parts List


① 1PC	② 1PC	③ 1PC	④ 1PC
⑤ 1PC	⑥ 2PCS	⑦ 1PC	⑧ 1PC
⑨ 2PCS	⑩ 2PCS	⑪ 2PCS	⑫ 1PC
⑬ 3PCS	⑭ 3PCS	⑮ 3PCS	⑯ 3PCS
⑰ 3PCS	⑱ 3PCS		

## PANEL LAYOUT




x 3

## STEP 1






A - x 10 | K - x 24 | CL - x 3 | CR - x 3

## STEP 2




B - x 5 | C - x 2

## STEP 3




**B -  x 5   C -  x 2**

## STEP 4




A-  x4 G-  x2 H-  x2

## STEP 5




## STEP 6




B - x 4 C - x 4




## STEP 7



## STEP 8




## STEP 9




B - x 4 C - x 6 D - x 2

## STEP 10




## STEP 11



C - x 4 | D - x 4


## STEP 12



E - x 8 | F - x 8

## STEP 13


DRAWERS X 3



A - x 15 | B - x 12 | C - x 9

## STEP 14


DRAWERS X 3



B - x 3


## STEP 15

## DRAWERS X 3




D - x 18 | K - x 18 | DL - x 3 | DR - x 3

## STEP 16



D - x 2 | L - x 2

## STEP 17



### TOPPLING FURNITURE WARNING:

- **ALWAYS** secure it with an anchor device.
- Please seek professional advice if you are in doubt of what fixing device to use.
- Regularly check that anchors are securely maintained.
- Use safety drawer locks to prevent children climbing.
- Stability of tall items may be affected by thick pile carpet or uneven floors .
- **Do not place unanchored televisions on furniture .**



**CAUTION:** for your safety when attaching the anchor fixings, please note the following:

- **Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson).**

