


anko

CLAIRE 2 DOOR CABINET

Instruction Manual



The photos and illustrations shown in this instruction manual are generic.
The manufacturer reserves the right to change any specification or feature without prior notice.

IMPORTANT: KEEP FOR FUTURE REFERENCE. READ CAREFULLY.

Assembly Instructions

43635887 CLAIRE 2 DOOR CABINET

WARNING:

DO NOT STAND, SIT OR LEAN ON THIS UNIT.

DO NOT USE THIS UNIT AS A STEP LADDER OR AS A CHOPPING SURFACE.

KEEP AWAY FROM CHILDREN AND BABIES.

ADULT ASSEMBLY REQUIRED.

USE ONLY ON A FLAT SURFACE.

DO NOT USE THIS UNIT UNLESS ALL BOLTS AND SCREWS ARE FIRMLY SECURED.

CARE INSTRUCTIONS:

TO BE ASSEMBLED ON A CLEAN, DRY AND SMOOTH SURFACE.

WIPE CLEAN WITH A SOFT DAMP CLOTH.

NEVER USE SCOURERS, ABRASIVES OR CHEMICAL SOLVENTS.

CHECK AND TIGHTEN ALL PARTS REGULARLY.

KEEP AWAY FROM MOISTURE AND DIRECT SUNLIGHT.

STORE IN A DRY PLACE.

FOR INDOOR AND DOMESTIC USE ONLY.



MAXIMUM SAFE LOAD:


15KG FOR TOP PANEL, 10KG FOR EACH SHELF.

1 Hardware List

A		6x35mm	14pcs	B		15x10mm	14pcs	C		8x30mm	22pcs
D		7x38mm	4pcs	E		3.5x14mm	46pcs	F		4x48mm	10pcs
G		19*19*1.5mm	4pcs	H		4mm	1pc	I			2pcs
J			8pcs	K		25*15*3mm	4pcs	L			2pcs
M			4pcs	N		6x30mm	2pcs	O		4x35mm	2pcs


2 Parts List

			
①	1pc	②	1pc
			
⑤	1pc	⑥	1pc
			
⑨	2pcs	⑩	1pc
			
⑪	1pc	⑫	1pc




STEP 1

→ A×4




STEP 2

● B×4 □ C×4




STEP 3




STEP 4

● D×4 □ C×4




STEP 5

A×6 B×6




STEP 6

F×10 C×10




STEP 7

 G×4  E×8




STEP 8

 K×4




STEP 9

→ A×4 ✓ L×2 ➡ E×2




STEP 10




STEP 11

 B×4  C×4




STEP 12

 J×8  E×8




STEP 13

► E×12 ◀ M×4 ◇ I×2



STEP 14



► E×16



STEP 15

— O×2

N×2



TOPPLING FURNITURE WARNING:

- **ALWAYS** secure it with an anchor device.
- **Please seek professional advice if you are in doubt of what fixing device to use.**
- **Regularly check that anchors are securely maintained.**
- Use safety drawer locks to prevent children climbing.
- **Stability of tall items may be affected by thick pile carpet or uneven floors .**
- **Do not place unanchored televisions on furniture .**



CAUTION: for your safety when attaching the anchor fixings, please note the following:

- **Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson).**



STEP 16

