


# HAZEL 2 DRAWER BEDSIDE TABLE

## Instruction Manual



The photos and illustrations shown in this instruction manual are generic.  
The manufacturer reserves the right to change any specification or feature without prior notice.

**IMPORTANT: KEEP FOR FUTURE REFERENCE. READ CAREFULLY.**

# Assembly Instructions

**K:43635948 | T:71785028 HAZEL 2 DRAWER BEDSIDE TABLE**

## **CARE INSTRUCTIONS:**

TO BE ASSEMBLED ON A CLEAN, DRY AND SMOOTH SURFACE.  
WIPE CLEAN WITH A SOFT DAMP CLOTH.  
NEVER USE SCOURERS, ABRASIVES OR CHEMICAL SOLVENTS.  
CHECK AND TIGHTEN ALL PARTS REGULARLY.  
KEEP AWAY FROM MOISTURE AND DIRECT SUNLIGHT.  
STORE IN A DRY PLACE.  
FOR INDOOR AND DOMESTIC USE ONLY.














## **WARNING:**

DO NOT STAND, SIT OR LEAN ON THIS UNIT.  
DO NOT USE THIS UNIT AS A STEP LADDER OR AS A CHOPPING SURFACE. KEEP  
AWAY FROM CHILDREN AND BABIES.  
ADULT ASSEMBLY REQUIRED.  
USE ONLY ON A FLAT SURFACE.  
DO NOT USE THIS UNIT UNLESS ALL BOLTS AND SCREWS ARE FIRMLY SECURED












## **MAXIMUM SAFE LOAD:**

10KG FOR TOP PANEL 5KG FOR EACH DRAWER.


## 1 Hardware List

A		6X30mm	10	B		6X35mm	18	C		15X10mm	18	D		4X35mm	8
E		3X12mm	32	G		3X15mm	4	J		L=80	2	K			4
O			1	P			1	Q			4	<div><div>12"</div><div></div><div>LX2</div><div></div><div>RX2</div></div>			

## 2 Parts List



① /1PC	② /1PC	③ /1PC	④ /1PC
			
⑤ /1PC	⑥ /1PC	⑦ /2PCS	⑧ /2PCS
			
⑨ /2PCS	⑩ /2PCS	⑪ /2PCS	
			

# PANEL LAYOUT





step:1

LX2




B -	X3
E -	X8

step:2







RX2




B -	X3
E -	X8




# STEP 3




A -		X3
C -		X3


# STEP 4




Q -		X4
A -		X3
C -		X3





**STEP 5**




**STEP 6**






O -		X1
B -		X4




# STEP 7





A -		X4
C -		X4






# STEP 8





B -		X8
C -		X8




# STEP 9





E		X12
D		X8


# STEP 10




**X2**



E		X4
J		X2

## STEP 11




## STEP 12



G –		X4
K –		X4

## STEP 13



P - X1

⚠ WARNING





**Children have died from furniture tipover.**

- ALWAYS secure it with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.
- Furniture type is at risk of toppling over.

**NEVER put a TV on this furniture**



**This is a permanent label. Do not remove!**

### TOPPLING FURNITURE WARNING:

- **ALWAYS** secure it with an anchor device.
- Please seek professional advice if you are in doubt of what fixing device to use.
- Regularly check that anchors are securely maintained.
- Use safety drawer locks to prevent children climbing.
- Stability of tall items may be affected by thick pile carpet or uneven floors .
- Do not place unanchored televisions on furniture .

**CAUTION:** for your safety when attaching the anchor fixings, please note the following:

- **Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson).**



WARNING: PLEASE SECURE YOUR FURNITURE WITH THE SUPPLIED WALL FIXING. SCAN THE CODE FOR MORE INFORMATION.

