


**anko**

# **CAMILLE 3 DRAWER BEDSIDE TABLE**

## Instruction Manual



The photos and illustrations shown in this instruction manual are generic.  
The manufacturer reserves the right to change any specification or feature without prior notice.

**IMPORTANT: KEEP FOR FUTURE REFERENCE. READ CAREFULLY.**

# Assembly Instructions





## 43636259 CAMILLE 3 DRAWER BEDSIDE TABLE

**CARE INSTRUCTIONS:** WIPE CLEAN WITH A SOFT DAMP CLOTH. NEVER USE SCOURERS, ABRASIVES OR CHEMICAL SOLVENTS. KEEP AWAY FROM MOISTURE AND DIRECT SUNLIGHT. STORE IN A DRY PLACE. FOR INDOOR USE ONLY.

**WARNING:** DO NOT STAND, SIT OR LEAN ON THE UNIT. DO NOT USE THIS UNIT AS A STEP LADDER. ENSURE THIS UNIT IS USED ONLY ON A FLAT SURFACE. DO NOT USE THIS UNIT UNLESS ALL BOLTS AND SCREWS ARE FIRMLY SECURED. DO NOT PLACE HOT OBJECTS SUCH AS COFFEE CUPS DIRECTLY ON THE SURFACE OF THIS FURNITURE ITEM. THIS ITEM IS FOR STORAGE PURPOSES ONLY. CONTAINS SMALL PARTS. IT IS TO BE ASSEMBLED BY AN ADULT. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.

**MAXIMUM SAFE LOAD:10KG FOR TOP, 5KG FOR DRAWER.**


### 1 Hardware List

A		6x35mm	34pcs	B		15x10mm	34pcs	C		6x30mm	10pcs	D		3.5x12mm	42pcs
E		4x40mm	4pcs	F		3x14mm	4pcs	G			4pcs	H		4x30mm	12pcs
I		4x25mm	3pcs	J			3pcs	K		4x25mm	1pc	L			4pcs
M							1pc	CL			3pcs	CR			3pcs
DL			3pcs	DR			3pcs								


## 2 Parts List

① 1pc	② 1pc	③ 1pc	④ 2pcs
⑤ 1pc	⑥ 2pcs	⑦ 1pc	⑧ 1pc
⑨ 3pcs	⑩ 3pcs	⑪ 3pcs	⑫ 3pcs
⑬ 3pcs			


## PANEL LAYOUT



## STEP1




## STEP2




## 2-PERSON ASSEMBLY



## STEP3




## STEP4




## STEP5



## STEP6



## STEP7



M-	x 1
M-	x 1



### TOPPLING FURNITURE WARNING:



- **ALWAYS** secure it with an anchor device.
- Please seek professional advice if you are in doubt of what fixing device to use.
- Regularly check that anchors are securely maintained.
- Use safety drawer locks to prevent children climbing.
- Stability of tall items may be affected by thick pile carpet or uneven floors .
- **Do not place unanchored televisions on furniture .**

**CAUTION:** for your safety when attaching the anchor fixings, please note the following:

- **Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson).**



## STEP8



9 x3

I -	x 3
J -	x 3