

# KMT说明书 折页 128g双铜 尺寸：89\*127mm

anko

K: 43-637-461 | T: 71-796-932  
Model No.: PW526

## Desktop Charger with Light User Manual

### Package contents:

- › USB-C cable
- › User manual



### 12 month warranty

Thank you for your purchase.

This product is warranted to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.


Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

MADE IN CHINA

### CUSTOMER SERVICE:

KMART AU: 1800 124 125  
KMART NZ: 0800 945 995  
TARGET AU: 1300 753 567

### Function overview:



### Specifications:

Input : 9V $\approx$ 3A

#### Wireless charging output power:

7.5W Max for compatible iPhone  
10W Max for compatible Samsung smartphone  
15W Max for other compatible Android models

Wireless speaker output: 3W

Bluetooth : 5.4


Transmission distance :  $\leq 10$ m

### Operation Instruction :

1. Connect the included cable to the power adapter with a rating of 27W or higher power and plug it into the power supply.

**NOTE:** 27W power adapter is not included.

2. Place the phone, which supports magnetic charging, onto the center of charging area. The charger will automatically align with the phone and charge it through magnetic attraction. If charging does not start, adjust the phone's position until it shows that charging is normal.



3. Lighting touch switch on the right side of the product, you can click to open, the order is: RGB running lights  $\rightarrow$  music rhythm  $\rightarrow$  night lights  $\rightarrow$  close.

4. In night light mode, long pressing the touch button for the first time can increase the brightness of the night light, and long pressing the touch button again can decrease the brightness of the night light.

5. The steps to use the Bluetooth speaker are as follows:

(1) Open the cell phone settings, turn on the Bluetooth, find pairing name "anko43637461", click to connect, after hearing the Bluetooth announcement, it means the Bluetooth connection is successful.

(2) The "+" button supports increasing volume and switching to the next track. Click it to increase volume; long press for 3 seconds to switch to the next track.

(3) The "-" button supports reducing volume and switching to the previous track. Click it to reduce volume; long press for 3 seconds to switch to the previous track.

(4) The button "⏸" supports playing/pausing songs and disconnecting Bluetooth. Click it to pause, click again to resume playback. Long press for 3 seconds to forcibly disconnect the Bluetooth connection and clear the current connection information. Repairing is required for the next use.

### LED Light:

Operation	Lighting Effect
Connecting the power supply	Green light on for 2 seconds
Single click	Switch between RGB running lights mode/music rhythm mode/night light mode/ turn off
Long press under night light mode	1st long press, brightness increases 2nd long press, brightness decreases

### Warning :

1. This product features input over-current and over-voltage protection. If it malfunctions or reduces output power, check for any abnormal conditions or improper use.

2. Avoid placing the product in water, fire, or extreme temperatures ( $>40^{\circ}\text{C}$  or  $<-20^{\circ}\text{C}$ ), and keep it out of reach of children.

3. Use a dry, soft cloth to clean the surface. Avoid using chemicals, soap, or detergent.

4. Improper use or placement of this product may shorten its lifespan or cause damage, which is not covered under warranty. Please use the product as directed.

5. The wireless charging efficiency may be affected by some phone cases. Make sure there is no metal foreign object between the charging pad and phone case when charging.

6. Require a minimum 30W wall charger input. (not included).