

# Ride on 6V Mini Quad Instruction Manual

2-4  
years

25  
kg  
MAXIMUM  
WEIGHT



**WARNING: SUITABLE FOR AGES 2-4 YEARS. MAXIMUM USER WEIGHT 25KG. TO REDUCE THE RISK OF INJURY, ADULT SUPERVISION REQUIRED. CHOKING HAZARD! CONTAINS SMALL ASSEMBLY COMPONENTS THAT ARE SMALL WITH FUNCTIONAL SHARP POINT AND EDGES. NEVER USE ON ROADWAYS, NEAR MOTOR VEHICLES, ON OR NEAR STEEP INCLINES OR STEPS, SWIMMING POOLS OR OTHER BODIES OF WATER. ALWAYS WEAR SHOES AND NEVER ALLOW MORE THAN 1 RIDER. PROTECTIVE EQUIPMENT SHOULD BE WORN (NOT INCLUDED). NOT TO BE USED IN TRAFFIC. ADULT ASSEMBLY REQUIRED.**

KEYCODE: 43-640-270

MADE IN CHINA

CUSTOMER SERVICE:  
KMART AU: 1800 124 125  
KMART NZ: 0800 945 995  
TARGET AU: 1300 753 567

Drawings in the manual are for reference only. Actual product may vary slightly. The manufacturer reserves the right to change any specification or feature without prior notice.

**IMPORTANT! PLEASE READ CAREFULLY BEFORE USE  
AND KEEP FOR FUTURE REFERENCE.**



## GUIDELINES FOR SAFE DRIVING:

1. Before children use this vehicle, an adult should carefully evaluate the driving area as well as the child's ability to drive the vehicle safely. Teach appropriate safety rules to your child before allowing operation of this vehicle. These rules should also be reviewed with other children who want to drive the vehicle.
2. Remain seated. A child who is not sitting on the seat when the vehicle is in motion could fall or cause the vehicle to tip over.
3. Do not operate the vehicle at night.
4. Do not operate the vehicle near steep inclines as it can cause the following:
  - Unsafe speed, even if the button is released.
  - Tipping
  - Loss of traction, causing the vehicle to slip.
  - Rolling backwards at an unsafe speed.
5. Avoid contact with moving/rotating parts, such as the motor, gear box, and wheels. Contact with these parts can cause serious injury.
6. Do not operate the vehicle when it's positioned on its side or upside-down.
7. Do not operate the vehicle near flammable vapours (gasoline, paint thinner, acetone, liquid wax, etc.) as the electrical switch emits an internal spark, which could cause an explosion or fire.
8. To prevent unsupervised use of the vehicle, disconnect the motor harness from the battery when the vehicle is not in use.

### ⚠ CAUTION: TO AVOID BATTERY LEAKAGE

- DO NOT incinerate used batteries.
- DO NOT dispose of batteries in fire.
- DO NOT mix old and new batteries or types of batteries.
- DO NOT short-circuit the supply terminals.
- Different types of batteries should not be mixed.
- Only batteries of the same or equivalent type as recommended are to be used.
- Exhausted batteries should be removed from the toy.
- Dispose of batteries safely.

### ⚠ WARNING:

TO REDUCE THE RISK OF INJURY, ADULT SUPERVISION IS REQUIRED. NEVER USE IN ROADWAYS, NEAR CARS, ON OR NEAR STEEP INCLINES OR STEPS, SWIMMING POOL OR OTHER BODIES OF WATER, ALWAYS WEAR SHOES, AND NEVER ALLOW MORE THAN ONE RIDER.

### ⚠ WARNING:

ADULT ASSEMBLY REQUIRED.





#### ATTENTION



Battery must be fully charged before use.

## BATTERY CHARGING:

### To recharge battery



10  
APPROX.



Never charge the battery longer than 12 hours.

1. Only use the provided 6 volt charger to charge the 6 volt battery. Power source or wall outlet must be 120 VAC and 60Hz. If the wall outlet is controlled by an on/off switch ensure that the switch is on.
2. Charge the battery after every use.
3. Never charge the battery longer than 12 hours. Failure to follow these instructions may damage your battery.
4. Once the battery is completely charged, disconnect the charger from the wall outlet and remove the charger plug from the battery.
5. The battery does not need to be removed from the vehicle. Keep the battery in the rear compartment when charging.
6. Before charging the battery, examine the battery case for cracks and other damage which may cause sulfuric acid to leak. If damage is detected, do not use the product any further.
7. The car can not be operated when the charger is connected to the car.

With a hose or submerge in water.

9. To clean the vehicle use a dry cloth. A non-wax furniture polish can be used to clean plastic parts. Do not spray the vehicle with a hose or submerge in water.

8. Avoid preparing the vehicle on sand, loose dirt, or gravel. Debris from this type of terrain can cause the motor and other metal components to fail.

7. Avoid operating the vehicle in wet or snowy conditions. Do not clean the vehicle by spraying water with a hose. Water or moisture can enter the vehicle and cause the motor to fail.

6. Driving through water or rainy weather, the vehicle should be stored inside.

5. Check all screws and other plastic components regularly and tighten as required. Covering screws with regular pieces of tape or broken pieces.

4. It is the responsibility of the adult who assembles this product to properly install all instructions included in the rotation. These parts must be assembled in the correct order.

3. Any parts showing evidence of wear should be replaced immediately.

2. Oil or grease moving parts periodically. Check all nuts and bolts often and tighten if necessary.

1. Maintenance instructions are located in the rear of the vehicle.

MAINTENANCE INSTRUCTIONS:

## VEHICLE CARE:

## ⚠️ WARNING:

### TO AVOID SERIOUS INJURY:

- Continuous adult supervision required.
- Never use near motor vehicles, streets, swimming pools, hills, steps, or sloped driveways.
- Never allow more than one rider.
- Riders should always be seated.
- Always wear shoes.
- Maximum weight: 25 kg.
- Periodically check hardware and tighten if necessary. Replace worn or broken parts if necessary.
- Do not recharge rechargeable battery without immediately.
- Only use the battery and charger specified by the manufacturer.
- The car can not be operated when the charger is connected to the car.
- Never use in large open areas. Avoid collisions.
- Never use or store in wet conditions.
- For use in large open areas. Avoid collisions.
- SKILL is required to avoid falls or collision.
- Never ride at night.

9. To clean the vehicle use a dry cloth. A non-wax furniture polish can be used to clean plastic parts. Do not spray the vehicle with a hose or submerge in water.

8. Avoid preparing the vehicle on sand, loose dirt, or gravel. Debris from this type of terrain can cause the motor and other metal components to fail.

7. Avoid operating the vehicle in wet or snowy conditions. Do not clean the vehicle by spraying water with a hose. Water or moisture can enter the vehicle and cause the motor to fail.

6. Driving through water or rainy weather, the vehicle should be stored inside.

5. Check all screws and other plastic components regularly and tighten as required. Covering screws with regular pieces of tape or broken pieces.

4. It is the responsibility of the adult who assembles this product to properly install all instructions included in the rotation. These parts must be assembled in the correct order.

3. Any parts showing evidence of wear should be replaced immediately.

2. Oil or grease moving parts periodically. Check all nuts and bolts often and tighten if necessary.

1. Maintenance instructions are located in the rear of the vehicle.

MAINTENANCE INSTRUCTIONS:

To STOP, release the foot pedal.



Once F or B have been selected, press the foot pedal to move forward or backwards.


Press F in order to drive the vehicle BACKWARD (in reverse). Put the vehicle in OFF before and after each use.

Press B to drive the vehicle FORWARD and B to drive the vehicle


in OFF before and after each use.

## DRIVING FUNCTION




Tool required (not included)		
Spare Hardware (for future use) : Please keep them away from small children		
Washer (x1)	M8 Nut (x1)	Screwdriver (not included)
Bolt (x1)	M8 Nut (x4)	Charger (x2)
Rear wheel (x2)	Wheel Cap (x4)	Wrench (x2)
Body (x1)	Front Fork (x1)	Front wheel assembly (x1)
Handlebar (x1)	Gearbox	
Wheel Axle (x2)	Washer (x4)	




## PARTS LIST:

**10**

Attach assembled front wheels onto the front body.  
**(NOTE: PLACE "A" ON THE FRONT)**


**11**

- Place the **HANDLEBAR** onto the front fork and align holes on handlebar & front fork.
- Insert the **BOLT** into hole on handlebar through the other side.
- Tighten the **BOLT** with a screwdriver (not included)




**1**

Remove the 4 rubber protectors from the wheel axles and dispose in the trash.

**Keep out of reach of children.**

**2**

Insert the rear axle through the hole in the **GEARBOX ASSEMBLY**.


**3**

Insert **REAR WHEEL, WASHER, M8 NUT** into both sides of the the rear axle, then tighten the **M8 NUT** with **WRENCH**.




6


8



7



9



4