

14.8 x 21cm

anko

# A4 LED Light Pad Instruction Manual


## Kit Includes

- > 1 x A4 LED light pad
- > 1 x USB-C cable
- > 1 x instruction sheet

## Specification

Model number: A4-21C  
Dimensions: 24.8cm(H) x 34.9cm(W)  
Illuminated space: 21.6cm(H) x 31.6cm(W)  
Brightness: 3 level adjustable  
Rated input: 5VDC  
Rated power: Max 4.1W  
Ta: 25°C

## Operation




1. Place the light pad on a flat surface, then connect to a power supply.



2. Hold power button down to turn on, to adjust the brightness, tap the power button to find your suitable brightness.



3. Place the artwork or design on top of the illuminated area. Then place tracing paper or paper on top to start sketching.



4. Once finished, hold down the power button to turn off.

anko

## Safety Warnings

For indoor use only  
The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.  
The cable is for use with lighting pad only, don't use for any other goods.  
Not for phone charging.

## Important

Do not expose this product to water; do not use it where it can fall into water.  
Do not drop this product or shake it to avoid damaging it.  
Store the product in a dust free and dry environment.  
Clean the product lightly with a dry cotton cloth.  
Do not use alcohol or any other chemical cleaners.  
Do not try to dismantle, modify or repair the product by yourself.  
Operate the product under supervision of parents.  
Use 5VDC SELV 4.1W power supply.

MADE IN CHINA

CUSTOMER SERVICE:  
KIMART AU: 1800 184 185  
KIMART NZ: 0800 945 995  
TARGET AU: 1300 753 567

KEYCODE: K: 43-660-841 | T: 71-933-672