

anko

Ride-On 6V Electric Quad  
Instruction Manual

18-36  
months

> forward foot switch motion  
> product dimensions: 41cm(H) x 59cm(W) x 36cm(D)



**CAUTION:**

- THIS PACKAGING CONTAINS SMALL PARTS.
- ADULT ASSEMBLY REQUIRED.
- REMOVE ALL PLASTIC BAGS AND PACKAGE TIES PRIOR TO GIVING TO CHILDREN.
- PROTECTIVE EQUIPMENT RECOMMENDED.
- NOT TO BE USED IN TRAFFIC.
- KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.


I. Specifications

|                               |                                          |
|-------------------------------|------------------------------------------|
| Suitable Ages                 | 18-36 months                             |
| Product Dimensions            | 41 x 59 x 36 cm                          |
| Maximum speed                 | 2.7km/h                                  |
| Motor                         | 30W                                      |
| Charger                       | Input: AC 100-240V<br>Output: DC8V/500mA |
| Battery                       | 6V4AH                                    |
| Operating Ambient Temperature | 0 - 40℃                                  |

II. Components List

|                                    |                                       |
|------------------------------------|---------------------------------------|
| 1. Body 1pc                        | 2. Handle bar 1pc                     |
| 3. J-shaped stick 1pc              | 4. Wheel cover 4 pcs                  |
| 5. Wheel 4 pcs                     | 6. Spacer 1pc                         |
| 7. Rear axle 1pc                   | 8. Tool 2pcs                          |
| 9. Nut 4pcs<br>(It's on the axle.) | 10. Bolt 1pc<br>(It's on the handle.) |

2



3

III. Assembly Instructions

< 1 >

1. Cut the plastic zip tie.

< 2 >

2. Release the nuts of rear wheel axle with the tools provided.

< 3 >

3. Insert the plastic spacer into the rear wheel axle and pass the axle through the hole of the motor. Then, insert the two rear wheels

< 4 >

4. Tighten two nuts by the tools provided.

4

< 5 >

5. Take out the protective sleeves, make sure the nuts stay in the axel.

< 6 >

6. Release the nuts of front wheel axle with the tools provided.

< 7 >

7. Insert the two front wheels and tighten two nuts by the tools provided.

< 8 >

8. Loosen the bolt and nut by a screwdriver(not included).

5

< 9 >

9. Install the J-Shaped stick at the assigned location as pictured. Then insert the bolt and tighten the nut with a screwdriver(not included).

< 10 >

10. Cover the wheel cap.

< 11 >

11. Loosen the screw of the seat by a screwdriver(not included) and open the seat.

< 12 >


12. Connect the cable terminal and the power terminal. Make sure the terminals are firmly installed.

6

< 13 >


13. Place the seat into the body, then tighten by the screws with a screwdriver(not included).

IV. Function and Operation



V. Battery and Charger Operating Guide.

1. The charging socket is located at the rear.
2. Only use the battery and charger which are provided.
3. Please do not play with the charger and battery because they are not toys.
4. The battery charging operation is only to be carried out by adults.
5. The battery shall be fully charged before first use. The battery charging time shall be 9-10 hours and can not exceed 15 hours.
6. Battery may get hot during charging.



1. Battery Warning:

1. When storing the car for a long period of time, charge the battery until full, then turn off the power switch. The battery should be recharged once every other month, or may otherwise have a shorter life span and risk deteriorating.
2. When installing the battery, it is important that the positive and negative poles are correctly connected. Short circuiting or positive and negative poles may result in damaging the toy.

7

**2. PRODUCT WARNING:**

1. There may be potential sharp edges, sharp points or small parts before the assembly of this product, and therefore this product shall be assembled by an adult.
2. To avoid suffocation, keep the plastic bag away from children. Dispose of all bags immediately.
3. The children shall correctly use the car under adult guidance, otherwise they may injure themselves or others.
4. The car is suitable for being driven on flat ground and it is strictly prohibited to be driven in dangerous places such as public roads, slopes and near swimming pools to prevent traffic and drowning accidents.
5. Please put on shoes and protective equipment before use(not included), such as a helmet, safety gloves, knee pads, etc. Regularly check whether the battery, charger, wire, plug, casing and other parts are damaged; if damage occurs, please cease to use this product until it has been repaired. This product is only allowed to be used by a child; the maximum load is 25kg, and therefore the overload is not allowed. Keep away from fire. Please keep the instruction manuals as it contains important information.

3. WARNING:

**WARNING**

To reduce the risk of injury, adult supervision is required. It is strictly forbidden to use on roadways, near motor vehicles, slopes, swimming pools and where there is water. The use of toys in areas other than private venues can cause safety hazards such as traffic accidents. Please wear shoes; and safety equipment (not included). This toy car can only be used simultaneously by one person. Keep away from kids until assembled by an adult, as there are potentially sharp edges, points or small parts.

**WARNING**

Do not mix alkaline battery, standard (carbon-zinc) battery or rechargeable (nickel-cadmium) battery. This toy contains a battery that is non-replaceable.

**WARNING**

Protective equipment should be worn. Not to be used in traffic.

KEYCODE: K: 43-495-119 11/2026  
MADE IN CHINA  
CUSTOMER SERVICE:  
KMART AU: 1800 124 125  
KMART NZ: 0800 945 995  
TARGET AU: 1300 753 567



8

Manufactured under license by  
INITIATE  
**PLANB**  
DREAM TO INNOVATE  
PLANB INTERNATIONAL HONG KONG LTD  
Suite 1505, 15th Floor, Cheong Cheong Plaza,  
77 Woody Rd, Tsimshatsui East, Kowloon, Hong Kong.