


8+
YEARS

STAR WARS™

RC MILLENNIUM FALCON™ MANUAL



2.4GHz




starwars.com

© & ™ Lucasfilm Ltd.


Attention: The included rechargeable battery is not fully charged prior to shipment and must be charged before the first use.

43-698-295

MILLENNIUM FALCON




REMOTE CONTROL



Other four buttons are for decorative purposes only and have no function.


BATTERY INSTALLATION

- 1. Unscrew to open battery cover, insert 4 x 1.5V AA batteries. (see Diagram1)
 - 2. Replace battery cover.
- Attention: Remove batteries after you have finished using your product.



LITHIUM BATTERY CHARGE INSTRUCTIONS



- Attention: Do not charge battery immediately after each play, let the battery cool down.
- 1. Turn off millennium falcon.
 - 2. Connect USB charging cable plug with millennium falcon charging interface, see Diagram 2.
 - 3. Plug the large end of USB cable into a 5Vd.c 2A charger (not supplied) or USB port only. The red LED light on the USB charging cable will light up and the green LED light will flash when charging.
 - 4. The red and green LED light will light up and will be solid after it has finished charging. Unplug the USB charging cable from computer's USB interface and disconnect with the millennium falcon.







CONTROL METHOD

- Attention: Select a large, wide-open area for flying, and make sure that there are no obstructions, animals, people or overhead powerlines nearby. Do not operate the millennium falcon in strong winds, rain or snow etc.
- 1. Set the millennium falcon power switch to "ON" and place flat ground, the LED lights on the millennium falcon will be flashing. Ensure you are least 2 metres from the back of the millennium falcon.
 - 2. Set the power on the remote control to "ON".
 - 3. Push the throttle lever up, you will hear one beep sound. Then push it down and you will hear beep sound again. If the power indicator on remote control stops flashing, the pairing is successful. If pairing is not successful, please repeat steps 1-3.
 - 4. The millennium falcon's gyroscope needs to be calibrated after pairing. Pull the throttle lever and direction lever to the lower right at the same time (see Diagram 3). You will hear one beep sound and the LED light on the millennium falcon will change from flashing to steady lighting. This means that the calibrating is successful.

- 5. There are two ways to fly / launch the millennium falcon:
Normal mode: Pull the throttle lever to the lower left and the direction lever to the lower right at the same time (see Diagram 4), the millennium falcon will unlock while the propeller starts to work.
Altitude hold mode: No need to unlock the millennium falcon, press the one key take off / landing button after pairing the millennium falcon. The millennium falcon will automatically rise to a height of about 1.5 metres. Now you can operate your millennium falcon.



HOW TO CONTROL THE MILLENNIUM FALCON

Throttle		Push the throttle lever up slowly, the millennium falcon will ascend. Pull the throttle lever down slowly, the millennium falcon will descend.
Rudder		Move the throttle lever to left, the millennium falcon will rotate anticlockwise. Move the throttle lever to right, the millennium falcon will rotate clockwise.
Elevator		Push the direction lever up the millennium falcon will fly forward. Pull the direction lever down the millennium falcon will fly backwards.
Aileron		Move the direction lever to left, the millennium falcon will fly to the left. Move the direction lever to right, the millennium falcon will fly to the right.

Tip: The LED light will flash slowly when the millennium falcon is low in battery. Please recharge the battery when the light is flashing.

MULTI DIRECTIONAL MODE

In multi directional mode, any side of the millennium falcon can be treated as the front of the millennium falcon.

How to transfer normal state to multi directional mode:

- 1. You can enter multi directional mode during stable flying or before flying.
- 2. Press the multi directional mode button, you will hear a beep sound, the LED light on the millennium falcon will flash, that means the millennium falcon has entered multi directional mode. You can play the millennium falcon under multi directional mode now.
- 3. Press the multi directional mode button again, you will hear a beep sound, the LED light on the millennium falcon will be lit, the millennium falcon will turn back to the normal flying mode.


HOW TO CHANGE THE SPEED MODE

- 1. Low speed mode: It is the default speed mode of millennium falcon.
- 2. Medium speed mode: Press the speed button, the millennium falcon will be in the medium speed mode when you hear two beep sounds.
- 3. High speed mode: Press the speed button again, the millennium falcon will be in the high speed mode when you hear three beep sounds. Press the speed button again, the millennium falcon will go back to the low speed mode when you hear a beep sound.


HOW TO TRIM THE MILLENNIUM FALCON

Slowly raise the throttle lever and let the millennium falcon lift-off the ground, you can use the trim to correct the action if the millennium falcon leans to the wrong direction.

- 1. If the millennium falcon drifts forward, press the backwards trim button as shown in Diagram 5 to trim it backwards until it stops drifting.
If the millennium falcon drifts backwards, press the forward trim button as shown in Diagram 5 to trim it forward until it stops drifting.



- 2. If the millennium falcon drifts to left, press the right trim button as shown in Diagram 6 to trim it to right until it stops drifting. If the millennium falcon drifts to right, press the left trim button as shown in Diagram 6 to trim it to left until it stops drifting.



HOW TO LAND THE MILLENNIUM FALCON

There are two ways to land the millennium falcon.

- 1. Press the one key take off / landing button to land the millennium falcon.
- 2. Hold the throttle lever down until the millennium falcon lands on the ground.

WARNING

- Please follow the instructions for correct installation and use. Some parts require assembly by an adult.
- The product contains small parts and is a choking hazard.
- Do not touch the hot motor and batteries.
- Do not touch working propellers.
- Do not fly towards yourself or other people.
- Adult supervision is required.
- Non-rechargeable batteries are not to be recharged.
- Do not mix old and new batteries or batteries of different types.
- Do not short circuit the battery or put the battery in fire.
- Do not leave the toy unattended while charging it.
- When the battery is low, please return the millennium falcon and recharge it.
- Charge the toy on non-flammable surfaces and keep it away from flammable items.
- Turn the charger off when the toy's battery is charged, and always unplug it from the toy.
- If the toy has been damaged, immediately stop use, unplug, and safely move the toy away from flammable materials.
- Follow the manufacturer's instructions for charging the toy. Do not charge longer than recommended.
- Do not use the product for a long time. Remove the battery after use.
- To avoid injury, do not touch the rotating parts.
- Do not impact or drop the millennium falcon or remote control.
- Please use a clean soft cloth to clean the product.
- The user is responsible for ensuring that the product will not cause harm to themselves or others.
- The manufacturers and dealers accept no responsibility for injuries or damage to property caused by improper use.
- The packaging and instructions contain important information, please keep for future reference.
- Only fly during the day and keep your millennium falcon within visual line-of-sight. This means being able to see the millennium falcon with your own eyes (rather than through a device) at all times.
- Do not fly your millennium falcon higher than 120 metres (400ft) above the ground.
- Keep your millennium falcon at least 30 metres away from other people.
- Do not fly your millennium falcon over or near an area affecting public safety or where emergency operations are underway (without prior approval). This could include situations such as a car crash, police operations, a fire and associated firefighting efforts, and search and rescue.
- Only fly one millennium falcon at a time.
- Do not fly over or above people. This could include beaches, parks, events, or sport ovals where there is a game in progress.
- Keep at least 5.5km away from controlled aerodromes if your millennium falcon weighs more than 100g. Flying within 5.5km of a non-controlled aerodrome or millennium falcon landing site (HLS) is possible, but only if no manned aircraft are operating to or from the aerodrome. If you become aware of manned aircraft operating to or from the aerodrome/HLS, you must manoeuvre away from the aircraft and land as soon as safely possible.
- Do not operate your millennium falcon in a way that creates a hazard to another aircraft, person or property.
- Respect personal privacy do not record or photograph people without their consent—this may breach state laws.

MADE IN CHINA

CUSTOMER SERVICE:

KMART AU: 1800 124 125 | **KMART NZ:** 0800 945 995 | **TARGET AU:** 1300 753 567