


INSTRUCTION MANUAL

anko
KING CAMP CHAIR

KING CAMP CHAIR



MAXIMUM CHAIR LOAD LIMIT: 100KG. SUITABLE FOR ONE PERSON ONLY. DO NOT STAND ON THE CHAIR. DO NOT USE THE CHAIR AS A STEP LADDER. TAKE CARE TO AVOID FINGER PINCHING WHEN FOLDING OR UNFOLDING THE CHAIR. ENSURE ALL LEGS AND FRAME LOCKS ARE FULLY EXTENDED BEFORE USE. USE ONLY ON A FLAT, EVEN SURFACE. FAILURE TO FOLLOW THESE WARNINGS MAY RESULT IN SERIOUS INJURY.

CARE INSTRUCTIONS: WIPE CLEAN WITH A DAMP CLOTH. DO NOT USE ABRASIVE MATERIALS OR SOLVENTS. ENSURE THE CHAIR IS CLEAN AND COMPLETELY DRY BEFORE STORING. STORE IN A DRY PLACE.

P1

HOW TO ADJUST THE GEAR POSITION

• Adjustment Steps

① Press and hold the adjustment button, then move the frame forward or backward. Release the button when it is aligned with the next hole.




⚠ Ensure the gear structure is securely locked into the hole before use.

② Repeat the adjustment on the other side. Ensure both sides are set to the same height level.



③ Three adjustment levels are available.




P2

HOW TO STORE

• Adjustment Steps

① Fold the frame. >> ② Use the restraint strap to secure the chair. >> ③ Place the folded and secured chair into the storage bag.




PRECAUTIONS ⚠

When the chair is adjusted to the maximum angle position



1. Do not bump it backward forcefully, as this may cause the chair to tip over.



2. Do not use your feet to push against the ground, as this may cause the chair to flip backwards.

P3

Made in China