

Electric Shark Water Blaster Instruction Manual

3+
years




BATTERY INSTALLATION:

Unscrew the battery cover, install the batteries and then close the cover.

Battery charge:


- Loosen the screw to open battery cover.
- Separate the rechargeable battery from connector.
- Connect the USB charging cable with rechargeable battery first (the battery connector will only fit in one way, do not force the connectors together), then plug the large end of the USB cable into a 5Vd.c. 2A charger (not supplied) or USB port. The red led light on the USB charging cable will light up when charging.
- The red led light extinguishes after it has finished charging. Disconnect USB charging cable from the USB port and then disconnect the rechargeable battery with USB charging cable.



HOW TO PLAY:


1

Open the lid and fill the water inlet with water. Close the lid.



2

Pull the trigger to spray water.



WARNING: CHOKING HAZARD

SMALL PARTS. NOT FOR CHILDREN UNDER 3 YEARS.

WARNING: THE TOY IS ONLY TO BE CONNECTED TO CLASS II EQUIPMENT BEARING THE SYMBOL. 

WARNING: RECHARGEABLE BATTERIES SHOULD BE CHARGED UNDER ADULT SUPERVISION. RECHARGEABLE BATTERIES ARE TO BE REMOVED FROM THE TOY BEFORE BEING CHARGED. CHARGE THE BATTERY BY SUPPLIED USB ONLY. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED. REMOVE BATTERIES FROM THE TOY WHEN NOT IN USE FOR AN EXTENDED TIME OR WHEN BATTERIES BECOME EXHAUSTED. BATTERY INSTALLATION BY AN ADULT IS REQUIRED. DISPOSE OF BATTERIES RESPONSIBLY. DO NOT DISPOSE OF IN FIRE.

WARNING: TO AVOID INJURY: DO NOT SHOOT AT A PERSON'S OR ANIMAL'S FACE OR EYES. USE ONLY CLEAR TAP WATER. USE OF OTHER LIQUID MAY BE HARMFUL OR DAMAGE PRODUCT. WHEN NOT IN USE DO NOT LEAVE PRODUCT PRESSURISED. EMPTY THE WATER TANK WHEN NOT IN USE.

WARNING: THE BATTERY CHARGER USED WITH THE TOY SHALL BE REGULARLY EXAMINED FOR DAMAGE TO THE SUPPLY CORD, PLUG, ENCLOSURE OR OTHER PARTS, AND IN THE EVENT OF DAMAGE, IT SHALL NOT BE USED UNTIL THE DAMAGE HAS BEEN REPAIRED.

WARNING: FOR SAFETY REASONS, REMOVE ALL TAGS, LABELS AND PLASTIC FASTENERS BEFORE GIVING THIS TOY TO YOUR CHILD

ADULT SUPERVISION REQUIRED.
PRODUCT MAY VARY FROM IMAGE SHOWN.
PLEASE KEEP PACKAGING FOR FUTURE REFERENCE.

MADE IN CHINA

43-701-735