




EIFFEL TOWER







BATTERY INSTALLATION



1 - Open the battery compartment.

2 - Insert 2 x 1.5V AA batteries with correct + and - polarities.



3 - Close the cover.





1





2





3






4









5



6





7





8


A



21





A






A




9




10






11




12






13









Please stick the wires with adhesive tape (not included) on the back side of this puzzle piece.




14




Please stick the wires with adhesive tape (not included) on the back side of this puzzle piece.




18




19






16




37 x4




20




21




22




23





38 x4



6 x2



24



ADULT ASSISTANCE AND SUPERVISION REQUIRED.
PRODUCT MAY VARY FROM IMAGE SHOWN.
PLEASE KEEP THE PACKAGING FOR FUTURE REFERENCE.

WARNING! STRANGULATION HAZARD. LONG CABLE.

WARNING: CHOKING HAZARD
SMALL PARTS. NOT FOR CHILDREN UNDER 3 YEARS.

WARNING: THIS TOY PRODUCES FLASHES THAT MAY
TRIGGER EPILEPSY IN SENSITISED INDIVIDUALS.

WARNING: FOR SAFETY REASONS, REMOVE ALL TAGS,
LABELS AND PLASTIC FASTENERS BEFORE GIVING
THIS TOY TO YOUR CHILD.



WARNING: BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY (+ AND -).
DO NOT MIX DIFFERENT TYPES OF BATTERIES OR NEW AND USED BATTERIES.
NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED. RECHARGEABLE
BATTERIES ARE ONLY TO BE CHARGED UNDER ADULT SUPERVISION. THE SUPPLY
TERMINALS ARE NOT TO BE SHORT-CIRCUITED. REMOVE BATTERIES FROM THE TOY
WHEN NOT IN USE FOR AN EXTENDED TIME OR WHEN BATTERIES BECOME
EXHAUSTED. BATTERY INSTALLATION BY AN ADULT IS REQUIRED. DISPOSE OF
BATTERIES RESPONSIBLY. DO NOT DISPOSE OF IN FIRE.

