

• anko

Instructions:

1. Remove all packaging before use and dispose of safely.
2. Use a suitable screwdriver to remove the safety screw and open the battery compartment cover.
3. Insert 3 x AAA size batteries.
4. Reinstall the battery compartment cover and the safety screw.
5. Move the switch on battery compartment to "ON" position, the light set should now be lit.
6. For indoor use only.
7. For decoration only. This is not a toy.


Warnings:

- The light set is designed for INDOOR USE ONLY.
- This unit is powered by 3 x AAA size batteries (not included).
- Open the battery door and insert 3 x AAA size batteries correctly. Pay attention to the polarities (+/-). The unit will not be powered up if you insert batteries in wrong polarity.
- Always remove the batteries if the unit is not going to be used for an extended period of time.
- Use only the size and type of battery specified. Batteries shall not be exposed to direct sunlight or heat source such as fire, oven or the like.
- When the battery power is low, the unit will not operate. You will need to insert new batteries. Do not mix new and old batteries.

BATTERY OPERATED LED LIGHT UP LANTERN (Model No.: BC26140S K: 43750900 / T: 72787519)




Contents:




60mm

60mm

Assembly Diagram:



Assembly Diagram:



80mm